



NVIDIA UFM Telemetry Documentation

v1.17.0

Table of Contents

1	Release Notes.....	6
1.1	Changes and New Features in This Release	6
1.1.1	New Features in v1.17.0	6
1.1.2	Changes in v1.17.0.....	6
1.2	System Requirements	6
1.3	Bug Fixes in This Release	6
1.4	Known Issues in This Release.....	7
1.5	Bug Fixes History.....	7
2	Overview	12
3	Software Management	13
3.1	Deploying UFM Telemetry.....	13
3.1.1	Bare Metal - Bringup Mode	13
3.1.2	Docker Container Mode	13
3.1.3	Docker Container Mode - High Availability	15
3.1.4	Bare Metal Mode	16
3.1.5	Bare Metal Mode - High Availability	17
3.2	Upgrading UFM Telemetry Software.....	18
3.2.1	Bare Metal - Bringup Mode	18
3.2.2	Docker Container Mode	18
3.2.3	Bare Metal Mode	19
4	Data Collection.....	20
4.1	Bare Metal - Bringup Mode	20
4.2	Bare Metal Mode	20
4.3	Container Mode	21
4.4	Cable Info Data.....	21
4.5	Port Counters	22
4.6	Switch Temperature	23
4.7	Switch Fans	24
4.8	Switch General	24
4.9	Bare Metal - Bringup Mode - amBER Format.....	25
5	Fluent Bit Export.....	26
5.1	Exporting Data Using Fluent Bit Export.....	26

5.2	Export Files	26
5.2.1	Export File Configuration Details.....	27
5.2.2	Msgpack Data Layout	27
5.2.3	Cset/Fset Filtering.....	28
5.3	Quick Start Guide for FluentD	29
5.4	Data Forwarding	30
5.5	UFM Telemetry Configuration Script	30
5.5.1	Controlling Fluent Bit Streaming	31
5.5.2	Controlling Target Destinations	31
5.5.3	Data Filtration.....	33
6	Settings and Configuration	35
6.1	Log File Rotation	36
6.2	Port Counters	36
6.3	Events.....	42
6.3.1	Enable PPCC	42
6.3.2	Switch Power Sensors Data	42
6.3.3	Switch Power Supplies Data	42
6.3.4	Managed Switch Data Collection	42
6.3.5	NVLink Info.....	43
7	Prometheus Endpoint Support	44
7.1	Prometheus Endpoint.....	44
7.2	Supported Formats	44
7.3	Data Filtering.....	44
7.3.1	Extended Counter Set Filtering.....	45
7.4	URL Prefixes Priority.....	45
7.5	Configuring Data Polling Endpoint.....	46
7.6	Prometheus Labels.....	47
7.7	Prometheus Label Generation	47
8	Distributed Telemetry - Switch Telemetry Agent.....	49
8.1	Overview	49
8.1.1	Terminology.....	49
8.2	Deployment	49
8.2.1	Running Distributed telemetry via HTTP API	50
9	Supported Telemetry Fields	52

9.1	Ports Counters Info	52
9.2	Cable Info	66
9.2.1	Supported Docker Statistics	69
9.3	Switch Info	72
9.4	PCI Info	73
9.5	NVLink Info.....	75
10	Document Revision History	77

You can download a PDF version [here](#).

About This Document

NVIDIA® UFM® Telemetry platform provides network validation tools to monitor network performance and conditions and to capture and stream rich real-time network telemetry information and application workload usage to an on-premise or cloud-based database for further analysis.

Technical Support

Customers who purchased NVIDIA products directly from NVIDIA are invited to contact us through the following methods:

- E-mail: enterprisesupport@nvidia.com
- Enterprise Support page: <https://www.nvidia.com/en-us/support/enterprise>

Customers who purchased NVIDIA M-1 Global Support Services, please see your contract for details regarding Technical Support.

Customers who purchased NVIDIA products through an NVIDIA-approved reseller should first seek assistance through their reseller.

Document Revision History

For the list of changes made to this document, refer to [Document Revision History](#).

1 Release Notes

These release notes pages provide information for NVIDIA UFM Telemetry such as changes and new features and bug fixes.

1.1 Changes and New Features in This Release

1.1.1 New Features in v1.17.0

- Renamed IB CC - PPCC counter
- Added support for Phy IB General Counters - number of packets drops due to MPR mismatch
- Added support for switch/module power usage
- Exposed SHARP telemetry

1.1.2 Changes in v1.17.0

N/A

1.2 System Requirements

Platform	Type and Version
OS and Kernel	<ul style="list-style-type: none">• RedHat 7.X• RedHat 8.X• RedHat 9.X• Ubuntu18• Ubuntu20• Ubuntu22
CPU	x86_64
OFED	MLNX_OFED 5.X

1.3 Bug Fixes in This Release

Ref. #	Description
3733919	Description: PEMI SNR does not return values - all 0
	Keywords: PEMI, SNR empty values
	Discovered in Release: 1.16
3828214	Description: PEMI SNR - only 4 lanes are shown in telemetry instead of 8
	Keywords: PEMI, SNR, 4 lanes
	Discovered in Release: 1.16
3841532	Description: Data from different sources show different timestamp
	Keywords: timestamp
	Discovered in Release: 1.16

Ref. #	Description
3807154	Description: Cannot set counter dt_num_imported_recent_ports, no context yet Keywords: log error, dt Discovered in Release: 1.16

1.4 Known Issues in This Release

N/A

1.5 Bug Fixes History

Ref. #	Description
3768320	Description: Missing RX Power from optical transceivers Keywords: RX Power, Optical Transceivers Discovered in Release: 1.15.3
3639657	Description: <code>telemetry_initialize.sh</code> ignores flags if they do not exist on the base configuration Keywords: <code>telemetry_initialize.sh</code> , flag Discovered in Release: 1.15.3
3689874	Description: Requesting specific fields in xcset leads to wrong Prometheus format output. Keywords: prometheus Discovered in Release: 1.15.6
3682405	Description: <code>generate_basic_results_csv</code> fails with 'ascii' codec due to inability to encode character '\xa0' Keywords: ascii, <code>generate_basic_results_csv</code> Discovered in Release: 1.15.6
3681267	Description: pack_data crashes Bringup CLI if directory does not exist Keywords: pack_data, Bringup CLI Discovered in Release: 1.15.6
3716902	Description: RxPowerType reported as empty Keywords: RxPowerType, empty Discovered in Release: 1.15.6
3734856	Description: HTTP server stops data transfer after 30 seconds Keywords: HTTP server, stop, 30 seconds Discovered in Release: 1.15.5
3745754	Description: reset_counters lacks option to reset disabled cables

Ref. #	Description
	<p>Keywords: reset_counters, disabled cables</p> <p>Discovered in Release: 1.15.6</p>
3751954	<p>Description: Running with CC configuration crashes after multiple iterations</p> <p>Keywords: CC configuration, Crash</p> <p>Discovered in Release: 1.15.0</p>
3667820	<p>NormalizedXmitData 100% - miscalculated</p> <p>Keyword: NormalizedXmitData 100%, miscalculated field</p> <p>Discovered in release: 1.14</p>
3597364	<p>Description: Multi-rate usage causes a crash</p> <p>Keywords: Coredump, Multi-rate</p> <p>Discovered in release: 1.14</p>
3648187	<p>Description: Hundreds of 'could not retrieve data for' warning messages</p> <p>Keywords: Warn, Warning</p> <p>Discovered in release: 1.14</p>
3590777	<p>Description: After upgrading UFM new telemetry data is not being collected and presented in UI Telemetry tab.</p> <p>Keywords: Telemetry, Coredump</p> <p>Discovered in release: 1.14</p>
3442081	<p>Description: The gen_metadata script fails and cannot generate metadata file.</p> <p>Keywords: Metadata, Labels</p> <p>Discovered in release: 1.12</p>
3331553	<p>Description: [installation]: no check for supervisord as a prerequisite.</p> <p>Keywords: run_bringup, supervisord</p> <p>Discovered in release: 1.12</p>
3546901	<p>Description: Invalid Cable Power data retrieved</p> <p>Keywords: Cable power, Power infinity</p> <p>Discovered in release: 1.13</p>
3481178	<p>Description: Fixed UFM-Telemetry data refresh delay.</p> <p>Keywords: Data Delay; Refresh;</p> <p>Discovered in release: 1.13.5</p>
3477852	<p>Description: Calculated values are set to (-1) when unavailable.</p> <p>Keywords: Unavailable Data;</p> <p>Discovered in release: 1.13.5</p>
3481011	<p>Description: Fixed cable voltage values presentation in microvolts (uV) instead of millivolts (mV).</p> <p>Keywords: Cable; Voltage; Unit of measurement;</p>

Ref. #	Description
	Discovered in release: 1.13.5
3438270	Description: Added support to starting UFM telemetry using the bringup tool with multi_port_sm configured. Keywords: Multiple HCAs; HCA list; Discovered in release: 1.13.5
3488824	Description: Fixed MADs statistics clearance between iterations. Keywords: MAD Statistics; Discovered in release: 1.13.5
3477561	Description: Fixed faulty Telemetry results in segmentation. Keywords: segfault; Discovered in release: 1.13.5
3461058	Description: UFM Telemetry log rotation applications are not used Keywords: Log, rotation applications Discovered in release: 1.13.0
3397908	Description: UFM Telemetry fails to start due to supervisord Keywords: supervisord, start failure Discovered in release: 1.12.0
3440964	Description: _MEI folders created in tmp are not removed Keywords: _MEI, temp folders Discovered in release: 1.12.0
3214566	Description: Dynamic Fabric unexpected header warning Keywords: Log warning, Dynamic Fabric Discovered in release: 1.10
3292572	Description: [systemd service]: executable path is not absolute Keywords: systemd Discovered in release: 1.11
3305919	Description: Timestamp error in CSV serialize of fset Keywords: timestamp Discovered in release: 1.11
3306476	Description: HTTP endpoint: fset "[CableInfo]Temperature" is not rendered Keywords: HTTP endpoint, Cable temperature Discovered in release: 1.11
3327188	Description: Missing amBER configuration for fluentbit Keywords: amber, Container configuration Discovered in release: 1.11
3327193	Description: CSV output contains redundant comma at EOL Keywords: csv

Ref. #	Description
	Discovered in release: 1.11
3332112	Description: Failed to execute script 'gen_metadata' Keyword: get_metadata Discovered in release: 1.11
3229888	Description: Error on launch_ibdiagnet.log Keywords: Log Error Discovered in release: 1.10
3225679	Description: Adding eff_ber counter to low_freq.cset file Keywords: cset, eff_ber Discovered in release: 1.10
N/A	Description: The Temperature fset does not contain labels Keywords: Temperature, labels Discovered in release: 1.9
N/A	Description: Cannot rename fields in fset Keywords: fset, events Discovered in release: 1.9
N/A	Description: The node_guid field in fsets is missing leading zeros Keywords: fset, events Discovered in release: 1.9
3051843	Description: Can't start telemetry without setting arg_12= to empty Keywords: startup failure Discovered in release: 1.9
3076045	Description: gen_metadata doesn't use a rules file when provided Keywords: metadata, labels Discovered in release: 1.9
2943459	Description: Custom labels lost after UFM restart Keywords: UFM restart, labels Discovered in release: 1.8
2921452	Description: raw_ber from UFM Telemetry doesn't match output of mlxlink -e -c -m Keywords: BER Discovered in release: 1.8
2923525	Description: Enabling BER collection on an NDR fabric causes segmentation fault of ibdiagnet Keywords: BER, ibdiagnet, segmentation fault Discovered in release: 1.8
3037715	Description: ConnectX-7 infiniband_CBW, Normalized_CBW are always zero

Ref. #	Description
	Keywords: InfiniBand
	Discovered in release: 1.8
3018638	Description: Normalized TX data returned 0% for ConnectX-7
	Keywords: TX data
	Discovered in release: 1.8

2 Overview

NVIDIA® UFM® Telemetry platform provides network validation tools to monitor network performance and conditions, and to capture and stream rich real-time network telemetry information and application workload usage to an on-premise or cloud-based database for further analysis.

UFM Telemetry can be used to monitor the basic fabric port counters and network statistics at a relatively high rate, or a more exhaustive set of performance metrics at a lower rate (referred to as Bringup mode). It can be configured to save collected data to disk, to stream via a Fluent forward protocol, or to make the data available via an http endpoint in csv or Prometheus format.

UFM Telemetry is packaged both as a docker image and as a bare metal tarball package.

3 Software Management

3.1 Deploying UFM Telemetry

Deploying UFM Telemetry can be done in the following modes:

- [Bare Metal - Bringup Mode](#)
- [Docker Container Mode](#)
- [Docker Container Mode - High Availability](#)
- [Bare Metal Mode](#)
- [Bare Metal Mode - High Availability](#)

3.1.1 Bare Metal - Bringup Mode

NVIDIA UFM Telemetry can be obtained as a tarball for installation on a Linux machine with all prerequisites installed.

To deploy the UFM Telemetry in Bringup mode, perform the following steps:

1. Make sure the following prerequisites are installed:
 - a. Python3
 - b. Python3-venv
 - c. Supervisor
2. Copy the tarball package to the targeted location.
3. Extract the package.

```
tar -xf ufm_telemetry-<version>.tar.gz
```

4. Start collection.

```
./bin/run_bringup .sh
CollectX: collection_start
This collects port counter and cable data every minute, uses HCA mlx5_0 and writes data to ./collection_data/clx-bringup-X for a period of 24hrs.
CollectX: help collection_start
Usage:
      options          defaults        Description
      -----          -----        -----
collection_start time|duration=n [s|m|h|d]    24h       Session duration
                  sample_rate=n [s|m|h|d]   60 seconds  Data sample rate
                  guids=[guid_list|guid_file] None      Target devices guid
                  counter_set=[file.xcset]  None      Counter list to be collected
                  hca=hca_name            mlx5_0   Device to access the fabric
                  cable|cable_info=[yes|no|once] yes      Collect cable info
                  nvlink_info=[yes|no]        no       Collect NVLink info
                  disconnected_cable=[yes|no] no       Collect disconnected cables info
                  reset_counters=t          false     Reset counters of fabric devices
                  compress_data=[yes|no]      yes      Compress files (if write_files=true)
                  mads_retries=n             2        Set number of retries for MADS
                  mads_timeout=n (msec)     500     Set timeout for MADS
                  force_hca=t                f        Avoid HCA state check
```

3.1.2 Docker Container Mode

NVIDIA UFM Telemetry is packaged as a docker image that should be loaded and deployed on a Linux machine with docker installed. This section describes how to deploy the UFM Telemetry docker image on a Linux machine.

To deploy the UFM telemetry, perform the following steps:

1. Make sure that docker is installed on the Linux machine.

```
[root@r-ufm ~]# docker -version
```

2. Start the docker service.

```
[root@r-ufm ~]# sudo service docker start
```

3. Pull the image.

```
[root@r-ufm ~]# export image=mellanox/ufm-telemetry:<version>
[root@r-ufm ~]# sudo docker pull $image
```

4. Create the default .ini files and place them in the local directory mapped to /config in the container and initialize the container configuration.

```
root@r-ufm ~]# sudo docker run -v /opt/ufm-telemetry/conf:/config --rm -d $image /get_collectx_configs.sh
"sample_rate=300;hca=mlx5_0;cable_info_schedule=1/00:00,3/00:00,5/00:00"
```

This collects port counter data every 5 minutes and uses HCA mlx5_0. It also collects cable info on the 1st, 3rd, and 5th day of the week at midnight, where:

- sample_rate: Frequency of collecting port counters
- hca: Card to use
- cable_info_schedule: Time of collecting cable info data (optional)

5. Create a container of UFM telemetry.

```
root@r-ufm ~]# sudo docker run --net=host --uts=host --ipc=host \
--ulimit stack=67108864 --ulimit memlock=-1 \
--security-opt seccomp=unconfined --cap-add=SYS_ADMIN \
--device=/dev/infiniband/ -v "/opt/ufm-telemetry/conf:/config" -v "/tmp/data:/data" -v "/opt/ufm/files/licenses:/opt/ufm/files/licenses/" --rm --name ufm-telemetry -d $image
```

6. Verify that UFM Telemetry is running.

- a. Make sure the UFM Telemetry container is up.

```
[root@r-ufm ~]# docker ps
```

- b. If the container name exists, access the shell of the container.

```
[root@r-ufm ~]# docker exec -it ufm-telemetry bash
```

- c. Review your configurations under `/config/launch_ibdiagnet_config.ini`.

7. View the UFM Telemetry configuration files.

```
root@ r-ufm ~]# ls -l /config/
-rw-r--r-- 1 3478 101 396 Apr 15 21:04 clx_config.ini
-rw-r--r-- 1 3478 101 2987 Apr 15 21:04 collectx.ini
-rw-r--r-- 1 3478 101 4257 Apr 15 21:04 launch_ibdiagnet_config.ini
-rw-r--r-- 1 3478 101 1912 Apr 16 12:03 supervisord.conf
```

- To watch and review the execution of the various components, you can check the log files under `/var/log`. Each component has a dedicated log file. Running the "ls -l" command will display all files under the folder. The following output shows only the relevant log files (other files have been omitted).

```
[root@r-ufm ~]# ls -l /var/log
-rw-r--r-- 1 root root 128393 Apr  3 10:49 launch_cableinfo.log
-rw-r--r-- 1 root root   467 Apr  3 09:35 launch_compression.log
-rw-r--r-- 1 root root 194566 Apr  3 10:49 launch_ibdiagnet.log
-rw-r--r-- 1 root root   798 Apr  3 09:35 launch_retention.log
-rw-r--r-- 1 root root   1729 Apr  3 09:56 supervisord.log
```

- To exit the UFM Telemetry docker context, run "exit" to return to the Linux machine context.
- To access the UFM Telemetry CLI, run the following command on the Linux machine:

```
[root@r-ufm ~]# docker exec -it ufm-telemetry clxcli
```

- For settings and configuration instructions, see [Settings and Configuration](#).

3.1.3 Docker Container Mode - High Availability

Requirements:

- An important requirement for the HA solution is to prepare a dedicated partition for DRBD to work with. Example of such a requirement: `/dev/sda4`.
- Install pcs and drbd-utils on both servers (using "`yum`" or "`apt-get install`", based on your OS).

On RH/CentOS, please run "yum install pcs drbd84-utils kmod-drbd84".

Procedure:

- Load (pull) the latest UFM Telemetry Docker image on both servers.

```
docker pull mellanox/ufm-telemetry:latest
```

- Run the Telemetry configuration command on both servers.

```
docker run --rm -i --name=config-telemetry \
-v /opt/ufm-telemetry/conf:/config \
-v /etc/systemd/system:/etc/systemd/system \
-v /var/run/docker.sock:/var/run/docker.sock \
mellanox/ufm-telemetry:latest \
/get_collectx_configs.sh \
--gen_service \
--config=ufm_telemetry
```

- Refresh systemd on both servers:

```
systemctl daemon-reload
```

- Create the `/opt/ufm-telemetry/licenses/` directory on the master server and copy the UFM Telemetry license file there.
- Download UFM-HA Package on both servers from [this link](#).
- Extract the HA package to `/tmp/`, and from there, run the installation command on both servers as follows:

In the below commands, "disk", the partition name, is assumed as /dev/sda4.

```
./install -l /opt/ufm-telemetry/ -d /dev/sda4 -p telemetry
```

7. Run the UFM-HA configuration command ONLY on the master server, as follows:

```
configure_ha_nodes.sh \
--cluster-password 12345678 \
--master-ip 192.168.10.1 \
--standby-ip 192.168.10.2 \
--virtual-ip 192.168.10.5
```

The `cluster-password` must be at least 8 characters long.

Change the values of in the above command with your server' information.

8. Start UFM Telemetry HA cluster. Run:

```
ufm_ha_cluster start
```

3.1.4 Bare Metal Mode

NVIDIA® UFM® Telemetry can be obtained as a tarball for installation on a Linux machine with all prerequisites installed.

To deploy the UFM Telemetry:

1. Ensure the following prerequisites are installed:
 - a. Python3
 - b. Python3-venv
 - c. Supervisor
2. Copy the tarball package to the target location.
3. Extract package.

```
tar -xf ufm_telemetry-<version>.tar.gz
```

4. Initialize and configure.

```
./bin/initialize_telemetry.sh --telemetry-dir /tmp/ufm_telemetry --config
"hcac=mlx5_0;sample_rate=300;data_dir=/tmp/clx_data;plugin_env_CLX_FILE_WRITE_ENABLED=1"
```

This collects port counter data every 5 minutes, and uses HCA mlx5_0 and writes data to /tmp/clx_data.

5. Start data collection.

```
supervisord --config /tmp/ufm_telemetry/conf/supervisord.conf
```

3.1.5 Bare Metal Mode - High Availability

NVIDIA® UFM® Telemetry can be obtained as a tarball for installation on a Linux machine with all prerequisites installed.

To deploy the UFM Telemetry:

1. Ensure the following prerequisites are installed:
 - a. Python3
 - b. Python3-venv
 - c. Supervisor
2. Copy the tarball package to the target location.
3. Extract package.

```
tar -xf ufm_telemetry -<version>.tar.gz
```

4. Initialize and configure.

```
./bin/initialize_telemetry.sh --telemetry-dir /tmp/ufm_telemetry --config  
"hca=mlx5_0;sample_rate=300;data_dir=/tmp/clx_data;plugin_env_CLX_FILE_WRITE_ENABLED=1" --  
gen_systemd_service
```

This collects port counter data every 5 minutes, and uses HCA mlx5_0 and writes data to /tmp/clx_data.

5. Download UFM-HA Package on both servers from [this link](#).
6. Extract the HA package to `/tmp/`, and from there, run the installation command on both servers as follows:

In the below commands, "disk", the partition name, is assumed as `/dev/sda4`.

```
./install -l /opt/ufm-telemetry/ -d /dev/sda4 -p telemetry
```

7. Run the UFM-HA configuration command ONLY on the master server, as follows:

```
configure_ha_nodes.sh \  
--cluster-password 12345678 \  
--master-ip 192.168.10.1 \  
--standby-ip 192.168.10.2 \  
--virtual-ip 192.168.10.5
```

The `cluster-password` must be at least 8 characters long.

Change the values of in the above command with your server' information.

8. Start UFM Telemetry HA cluster. Run:

```
ufm_ha_cluster start
```

To check the status of your UFM Telemetry HA cluster, run:

```
ufm_ha_cluster status
```

To perform failover, run:

```
ufm_ha_cluster failover
```

To perform takeover, run:

```
ufm_ha_cluster takeover
```

3.2 Upgrading UFM Telemetry Software

Upgrading UFM Telemetry requires removing the previous package, pulling the new version of the UFM telemetry package, configuring the telemetry, and starting it from the new installation package.

The upgrade procedure can done in the three modes:

- [Bare Metal - Bringup Mode](#)
- [Docker Container Mode](#)
- [Bare Metal Mode](#)

3.2.1 Bare Metal - Bringup Mode

1. Stop previous collection. Run:

```
./bin/run_bringup.sh  
CollectX: collection_stop
```

2. Follow instructions described in [Deploying UFM Telemetry - Bare Metal Mode](#) with the new UFM Telemetry version.
3. If needed, apply the previous configuration changes.

3.2.2 Docker Container Mode

1. Stop the previous ufm-telemetry container.

```
[root@r-ufm ~]# docker stop ufm-telemetry
```

2. Pull the new UFM Telemetry image.

```
[root@r-ufm ~]# export image=mellanox/ufm-telemetry:rhel7.3_x86_64_ofed5.1-2.3.7_release_1.6_latest  
[root@r-ufm ~]# docker pull $image
```

3. Create a container for new UFM Telemetry.

```
[root@r-ufm ~]# docker run --net=host --uts=host --ipc=host \  
--ulimit stack=67108864 --ulimit memlock=-1 \  
--security-opt seccomp=unconfined --cap-add=SYS_ADMIN \  
--device=/dev/infiniband/ -v "/opt/ufm-telemetry/conf:/config" -v "/tmp/data:/data" --rm --  
name ufm-telemetry -d $image
```

4. Configure the UFM Telemetry based on the new configurations.

```
[root@r-ufm ~]# docker run -v /opt/ufm-telemetry/conf:/config --rm -d $image /get_collectx_configs.sh  
sample_rate=300;hca=mlx5_0;cable_info_schedule=1/00:00,3/00:00,5/00:00"
```

3.2.3 Bare Metal Mode

1. Stop previous collection. Run:

```
kill $SUPERVISORD_PID # send sigterm to the supervisord proc
```

2. Follow instructions described in [Deploying UFM Telemetry - Bringup Mode](#) with the new UFM Telemetry version.
3. If needed, apply the previous configuration changes.

4 Data Collection

NVIDIA® UFM® Telemetry uses the configuration file `launch_ibdiagnet_config.ini` to control the process of collecting the data. It collects two types of data: Cable info and port counters.

Port counters are collected periodically by setting the parameter `sample_rate` in seconds.

4.1 Bare Metal - Bringup Mode

The Bare Metal Bringup mode is the most common output format designed for debugging a cluster. The following command shows the help menu of the generated basic report command.

Description:

```
Dump basic results IB report for a given date or range of dates
```

Usage:

```
generate_basic_results_csv TIME [report_type=] [out=] [show_raw_data=]
TIME can be specified as:
    date=
        past=n[hours|days] : relative to the current time on the server.
        from= to=
[out=] to specify output file
[show_raw_data=t|f] boolean to show raw data as is. Default: f
```

Example:

```
generate_basic_results_csv past=10m out=basic_ib.csv
```

4.2 Bare Metal Mode

By default cable info data will not be collected. To enable its collection, add the following flag:

```
plugin_env_CLX_EXPORT_API_DISABLE_CABLEINFO=0
```

When enabled, cable info data is collected, by default, on every run. It is possible to change the collection frequency to be once every `num_iterations` using the following setting:

```
plugin_env_CLX_EXPORT_API_CABLE_RUN_ONCE=1
```

To work with the collected data, you may use the Telemetry CLI, which can be accessed as follows:

```
./bin/clxcli
CollectX: set_data_root /tmp/clx_data
CollectX: set_data_template {{year}}/{{month}}{{day}}/{{hash1023}}/{{source}}/{{tag}}{{id}}.bin
```

4.3 Container Mode

Cable info data is collected based on a weekly schedule, set with the parameter `cable_info_schedule`. Time parameter is in the format "day/hrs:mins". For daily collection, it is "hrs:mins".

It is possible to collect the data multiple times during the week. To do that use a comma to separate the times at which collection is to take place. For example,

- `cable_info_schedule= 5/00:00` - collects cable info data on 5th day of the week at midnight
- `cable_info_schedule= 12:00` - collects cable info data midnight at 12:00 every day
- `cable_info_schedule= 5/00:00,12:00` - combines the previous two examples

To work with the collected data, you may use the Telemetry CLI, which can be accessed as follows:

```
[root@r-ufm145 ~]# docker exec -it ufm-telemetry clxcli
Read configuration from: /opt/mellanox/collectx/etc/collectx.ini
agx_data_root = /data
Loaded 2 schemas from /data/schema/schema*.json

CollectX:
```

4.4 Cable Info Data

The main commands to query and retrieve cable info data are `cable_times` and `cable_info`.

- `cables_times` - dump times and file names of cable info data files, and you can redirect the output to a file
- `cable_info` - dump cable info for a given date or range of dates

The following presents the help menu of the `cable_time` command:

```
CollectX: help cable_times
Usage:
    cable_times [TIME] [out=]
    [TIME] is one the following:
        date=
        past=n[hours|days]

Description:
    Dump times and file names of cable info data files

Examples:
    cable_times
    cable_times date=jun04
    cable_times past=15d out=out.csv
```

Example for `cable_time` command:

```
CollectX: cable_times
Opened 202 files in 0.05 seconds
Cable
-----
idx  Date Time      Filename
---  -----
1   2020-07-26 04:13  ../../cables_1595725983912963.bin
3   2020-07-26 04:28  ../../cables_1595726884030804.bin
```

Help menu of `cable_info` command:

```
CollectX: help cable_info

Usage:
    cable_info [TIME] [out=]
    [TIME] is one of the following:
        last
        date=
        past=n[hours|days]
    [out=] is to specify output file (optional)

Description:
    Dump cable info for a given date or range of dates.
    If "last" arg is given, dumps only the last file.
    If "out=" file name specified, data will be also dumped to that file.

Examples:
    cable_info filename
    cable_info file=filename
    cable_info last
    cable_info date=jun04
    cable_info past=15d out=cable_info.csv
```

Example for `cable_info` command:

```
cable_info /.../cables_1595764809124997.bin

time,source,timestamp,port,lid,guid,port_name,vendor,oui,pn,sn,rev,length,type,supportedspeed,temperature,powerclass,
nominalbitrate,cdrenabletxrx,inpupeq,outputamp,outputtemp,fw_version,attenuation_2.5_5_7_12,rx_power_type,
rx_power.1.mw,rx_power.1.dbm,rx_power.2.mw,rx_power.2.dbm,rx_power.3.mw,rx_power.3.dbm,rx_power.4.mw,
rx_power.4.dbm,tx_bias.1,tx_bias.2,tx_bias.3,tx_bias.4,tx_power.1.mw,tx_power.1.dbm,tx_power.2.mw,tx_power.2.dbm,tx_
power.3.mw,tx_power.3.dbm,tx_power.4.mw,tx_power.4.dbm,cdr_tx_rx_loss_indicator,adaptive_equalization_fault,tx_rx_
lol_indicator,temperature_alarm_and_warning,voltage_alarm_and_warning,rx_power_alarm_and_warning,tx_bias_alarm_and_
warning,tx_power_alarm_and_warning,diag_supply_voltage,transmitter_technology,eth_com_codes_ext,datacode,lot,tx_ada_
ptive_equalization_freeze,rx_output_disable,tx_adaptive_equalization_enable,
2020-07-26T15:00:12.742710,cable_info,1595764812742710,1,117,0x248a0703008b20ec,ufm-hercules-01/U1/
P1,Mellanox,0x2c9,MC2207130-002,MT1442VS07035,A3,2 m,Copper cable- unequalized,SDR/DDR/QDR/FDR,N/A,1,0,N/A N/A,N/
A,N/A,N/A,N/A,5 8 11
0,OMA,0.0,-999.999023438,0.0,-999.999023438,0.0,-999.999023438,0.0,-999.999023438,*,*,*,*,0.0,-999.999023438,0.0,-9
99.999023438,0.0,-999.999023438,0.0,-999.999023438,0.0,0,0,0,0,0,0,160,0,14-11-27,8224,0,0x0,0x0,
2020-07-26T15:00:12.742710,cable_info,1595764812742710,1,104,0xe41d2d0300109610,mslib-e2edmnz-02/U1/
P1,Mellanox,0x2c9,MC2207130-002,MT1442VS07035,A3,2 m,Copper cable- unequalized,SDR/DDR/QDR/FDR,N/A,1,0,N/A N/A,N/
A,N/A,N/A,N/A,5 8 11
0,OMA,0.0,-999.999023438,0.0,-999.999023438,0.0,-999.999023438,0.0,-999.999023438,*,*,*,*,0.0,-999.999023438,0.0,-9
99.999023438,0.0,-999.999023438,0.0,-999.999023438,0.0,0,0,0,0,0,0,160,0,14-11-27,8224,0,0x0,0x0,
2020-07-26T15:00:12.742710,cable_info,1595764812742710,3,104,0xe41d2d0300109610,mslib-e2edmnz-02/U1/
P3,Mellanox,0x2c9,MC2207130-002,MT1411VS08914,A3,2 m,Copper cable- unequalized,SDR/DDR/QDR/FDR,N/A,1,0,N/A N/A,N/
A,N/A,N/A,N/A,5 8 11
0,OMA,0.0,-999.999023438,0.0,-999.999023438,0.0,-999.999023438,0.0,-999.999023438,*,*,*,*,0.0,-999.999023438,0.0,-9
99.999023438,0.0,-999.999023438,0.0,-999.999023438,0.0,0,0,0,0,0,0,160,0,14-03-25,8224,0,0x0,0x0,
2020-07-26T15:00:12.742710,cable_info,1595764812742710,1,187,0xe41d2d03005d2250,ip-forwarder/U1/
P1,Mellanox,0x2c9,MC2207130-002,MT1411VS08914,A3,2 m,Copper cable- unequalized,SDR/DDR/QDR/FDR,N/A,1,0,N/A N/A,N/
A,N/A,N/A,N/A,5 8 11
0,OMA,0.0,-999.999023438,0.0,-999.999023438,0.0,-999.999023438,0.0,-999.999023438,*,*,*,*,0.0,-999.999023438,0.0,-9
99.999023438,0.0,-999.999023438,0.0,-999.999023438,0.0,0,0,0,0,0,0,160,0,14-03-25,8224,0,0x0,0x0,
```

4.5 Port Counters

The `port_counters` command is used to extract data in CSV format. It dumps counters matching a given text fragment or "counterset" for a date or range of dates.

Following is the help menu of `port_counters` command:

```
CollectX: help port_counters

Usage:
    port_counters [TAGS] [TIME] [out=]

    [TAGS] is a list of countersets/name fragments.
    [TIME] can be specified as:
            date=
            past=n[hours|days]
            from= to=
    [out=] to specify output file (optional)

Description:
    Dump port_counters matching a given fragment/counterset for a
    given date or range of dates.

Example:
    port_counters error past=10m
    port_counters error date=jul16 out=error_dump.csv
```

The following is an example of a `port_counters` command run:

4.6 Switch Temperature

The `switch_temperature` command is used to dump switch temperature info for a given date or range of dates into CSV files.

The following presents the help menu of the `switch_temperature` command:

```
CollectX: help switch_temperature
Usage:
    switch_temperature [TIME] [out=]
    [TIME] is one of the following:
        last
        date=
        past=n[hours|days]
    [out=] is to specify output file (optional)
Description:
    Dump switch temperature info for a given date or range of dates.
    If "out=" file name specified, data will be also dumped to that file.
Examples:
    switch_temperature filename
    switch_temperature file=filename
    switch_temperature date=apr21
    switch_temperature past=15d out=switch_temperature.csv
```

The following is an example of a switch temperature command run:

```
CollectX: switch_temperature past=10m out=switch_temperature.csv
time,source,timestamp,node_guid,sensor_index,mtmp_sensor_name,temperature,max_temperature,
12T17:05:16.332772,0xe41d2d030003e450,1649783116332772,0xe41d2d030003e450,0,,47,51,
2022-04-12T17:05:16.332772,0xe41d2d030003e450,1649783116332772,0xe41d2d030003e450,1,,30,33,
2022-04-12T17:05:16.332772,0xe41d2d030003e450,1649783116332772,0xe41d2d030003e450,2,,33,37,
2022-04-12T17:05:16.332772,0xec0d9a0300b41a50,1649783116332772,0xec0d9a0300b41a50,0,,58,66,
2022-04-12T17:05:16.332772,0xec0d9a0300b41a50,1649783116332772,0xec0d9a0300b41a50,1,,27,31,
2022-04-12T17:05:16.332772,0xec0d9a0300b41a50,1649783116332772,0xec0d9a0300b41a50,2,,33,37,
...
```

4.7 Switch Fans

The `switch_fans` command is used to dump switch fans info for a given date or range of dates into CSV files.

The following presents the help menu of the `switch_fans` command:

```
CollectX: help switch_fans
Usage:
    switch_fans [TIME] [out=]
    [TIME] is one of the following:
        last
        date=
        past=n[hours|days]
    [out=] is to specify output file (optional)
Description:
    Dump switch fans info for a given date or range of dates.
    If "out=" file name specified, data will be also dumped to that file.
Examples:
    switch_fans filename
    switch_fans file=filename
    switch_fans date=jun04
    switch_fans past=15d out=switch_fans.csv
```

The following is an example of a `switch_fans` command run:

```
CollectX: switch_fans past=10m out=switch_fans.csv
time,source,timestamp,node_guid,sensor_index,fan_speed,
2020-10-04T17:36:05.287397,0xe41d2d0300169e40,1601822165287397,0xe41d2d0300169e40,1,10288,
2020-10-04T17:36:05.287402,0xe41d2d0300169e40,1601822165287402,0xe41d2d0300169e40,2,8823,
2020-10-04T17:36:05.287403,0xe41d2d0300169e40,1601822165287403,0xe41d2d0300169e40,3,10608,
2020-10-04T17:36:05.287404,0xe41d2d0300169e40,1601822165287404,0xe41d2d0300169e40,4,9118,
...
```

4.8 Switch General

The `switch_general` command is used to dump general switch info for a given date or range of dates into CSV files.

The following presents the help menu of `switch_general` command:

```
CollectX: help switch_general
Usage:
    switch_general [TIME] [out=]
    [TIME] is one of the following:
        last
        date=
        past=n[hours|days]
    [out=] is to specify output file (optional)
Description:
    Dump switch general info for a given date or range of dates.
    If "out=" file name specified, data will be also dumped to that file.
Examples:
    switch_general filename
    switch_general file=filename
    switch_general date=jun04
    switch_general past=15d out=switch_general.csv
```

The following is an example of a `switch_general` command run:

```
CollectX: switch_general past=10m out=switch_general.csv
time,source,timestamp,node_guid,serial_number,part_number,revision,product_name,random_fdb_cap,linear_fdb_cap,linea
ri_fdb_top,mcast_fdb_cap,optimized_svlv_mapping,port_state_change,life_time_value,def_mcast_not_pri_port,def_mcast_p
ri_port,def_port,part_enf_cap,lids_per_port,mcast_fdb_top,epn0,filter_raw_outb_cap,filter_raw_inb_cap,outb_enf_cap,
inb_enf_cap,
2020-10-25T11:41:05.183039,0xe41d2d0300169e40,1603618865183039,0xe41d2d0300169e40,MT1510X10802,MSB7700-
EB2F,A6,Scorpion IB EDR,0,49152,7936,16383,1,1,19,255,255,0,32,0,49183,1,1,1,1,
2020-10-25T11:42:05.559284,0xe41d2d0300169e40,1603618925559284,0xe41d2d0300169e40,MT1510X10802,MSB7700-
EB2F,A6,Scorpion IB EDR,0,49152,7936,16383,1,1,19,255,255,0,32,0,49183,1,1,1,1,
```

2020-10-
...

4.9 Bare Metal - Bringup Mode - amBER Format

amBER is an output format designed for debugging a cluster in its bringup stage.

The following shows the help menu of the generate amBER report command:

```
CollectX: generate_amber_ib_csv past=1h out=amber_ib.csv
```

For example:

```
CollectX: help generate_amber_ib_csv
Usage:
    generate_amber_ib_csv TIME [report_type=] [out=] [show_raw_data=]
    TIME can be specified as:
        date=
        past=n[hours|days] : relative to the current time on the server.
        from= to=
    [out=] to specify output file
    [show_raw_data=t|f] boolean to show raw data as is. Default: f
Description:
    Dump amBER IB report for a given date or range of dates
Example:
    generate_amber_ib_csv past=10m
    generate_amber_ib_csv date=jul16 out=amber_ib.csv
    TIME:
        from='sep 23, 2021 16:05:00'
        from='2021-09-23 16:05:00'
```

5 Fluent Bit Export

NVIDIA® UFM® Telemetry adds the ability to stream to multiple destinations using Fluent Bit. The streaming implementation can stream to any Fluent Bit export plugin, with the "Forward" plugin being particularly useful as it allows sending data to a customer-maintained Fluent Bit or FluentD instance which the customer can then configure as based on their requirements.

5.1 Exporting Data Using Fluent Bit Export

To export collected data from the UFM Telemetry docker image:

1. Load, configure, and run the docker image. See the details in the "[Software Management](#)" chapter.
2. Connect to "ufm-telemetry docker bash".

```
[root@r-ufm ~]# sudo docker exec -it ufm-telemetry bash
```

3. Configure/create export files `*.exp` in export directory `/config/fluent_bit_configs/` and set `enable=1` for plugins you want to run. Please see details in the "[Export Files](#)" section.
4. Enable Fluent Bit export by setting `plugin_env_FLUENT_BIT_EXPORT_ENABLE=1` in `/config/launch_ibdiagnet_config.ini`.

```
[root@r-ufm ~]# vi /telemetry.config/launch_ibdiagnet_config.ini
...
[fluentbit_export]
plugin_env_FLUENT_BIT_EXPORT_ENABLE=1
plugin_env_FLUENT_BIT_CONFIG_DIR=/telemetry.config/fluent_bit_configs
plugin_env_LD_LIBRARY_PATH=/opt/mellanox/collectx/lib
...
```

Alternatively, you may do this using the configuration script `configure_ufm_telemetry_target.py` by running:

```
[root@r-ufm ~]# /config/configure_ufm_telemetry_target.py enable-streaming
```

This changes the value of the `plugin_env_FLUENT_BIT_EXPORT_ENABLE` parameter in the `launch_ibdiagnet_config.ini` file. See section "[Controlling Fluent Bit Streaming](#)" for more details.

5. Run destination programs that will receive data. See more details in the "[Data Forwarding](#)" section.
6. See the data on the receiving side.

Ibdiagnet will collect and export data periodically as configured by `launch_ibdiagnet_config.ini` file using the `sample_rate` parameter.

5.2 Export Files

Export destinations are set by configuring `.exp` files or creating new ones. All export files are placed in the export configuration folder `/config/fluent_bit_configs`. The easiest way to start is to use documented example exp-files for the following plugins:

- forward
- stdout
- stdout_raw (this plugin is presented only in the Fluent Bit version installed in the UFM Telemetry docker image)

All plugins are disabled by default. To enable a plugin, set `enable=1`.

5.2.1 Export File Configuration Details

Each export destination has the following fields:

- name - configuration name
- plugin_name - Fluent Bit plugin name
- enable - 1 or 0 values to enable/disable this destination
- host - the host for Fluent Bit plugin
- port - port for Fluent Bit plugin
- msgpack_data_layout - the msgpacked data format. Default is `flb_std`. The other option is `custom`. See section "[Msgpack Data Layout](#)" for details.
- plugin_key=val - key-value pairs of Fluent Bit plugin parameter (optional)
- counterset/fieldset - file paths (optional). See the details in section "[Cset/Fset Filtering](#)".

Use "#" to comment line.

5.2.2 Msgpack Data Layout

Data layout can be configured using .exp files by setting "msgpack_data_layout=layout".

Two layouts are available:

1. "flb_std" data layout is an array of 2 fields: timestamp double value and a plain dictionary (key-value pairs). The standard layout is appropriate for all Fluent Bit plugins. For example:

```
[timestamp_val, {"timestamp":>ts_val, type=>"counters/events", "source":>"source_val", "key_1":>val_1,
"key_2":>val_2,...}]
```

2. "custom" data layout is a dictionary of meta-fields and counter fields. Values are placed into a separate plain dictionary. Custom data format can be dumped with "stdout_raw" output plugin of fluent-bit installed or can be forwarded with "forward" output plugin.

Counters example:

```
{"timestamp":>timestamp_val, "type":>"counters", "source":>"source_val", "values":> {"key_1":>val_1,
"key_2":>val_2,...}}
```

Events example:

```
{"timestamp":>timestamp_val, "type":>"events", "type_name":>"type_name_val", "source":>" source_val",
"values":> {"key_1":>val_1, "key_2":>val_2,...}}
```

5.2.3 Cset/Fset Filtering

Each export file can optionally use one cset and one fset file to filter UFM Telemetry counters and events data.

- Cset file contains tokens per line to filter data with "type"="counters".
- Fset contains several blocks started with the header line [event_type_name] and tokens under that header. Fset file is used to filter data with "type"="events".
 - Event type names can be prefixed to apply the same tokens to all fitting types. For example, to filter all ethtool events use [ethtool_event_*].

If several tokens are needed to be matched simultaneously use "tok1+tok2+tok3". Exclusive tokens are available too: line "tok1+tok2-tok3-tok4" will filter names that match both tok1 and tok2 and do not match tok3 or tok4.

Both events and counters can be extended with aliased fields and new constant fields.

- "meta_field_aliases:exact_name=alias" will add new field/counter with name "alias_name" and copied value from the existing field/counter "exact_name".
- "meta_field_add:new_name=constant_value" will add new filed/counter with a name "new_name" and value "constant_value"

New fields should have unique names, otherwise, they will be ignored.

For more details see documentation in the files `ufm_enterprise.cset` and `ufm_enterprise.fset` under `/config/fluent_bit_configs`.

The following is the content of `/config/fluent_bit_configs/ufm_enterprise.cset`:

```
# put tokens on separate lines

# Tokens are the actual name 'fragments' to be matched
#   port$          # match names ending with token "port"
#   ^port           # match names starting with token "port"
#   ^port$          # include name that is exact token "port"
#   port+xmit      # match names that contain both tokens "port" and "xmit"
#   port-support    # match names that contain the token "port" and do not match the "--" token "support"
#   -port           # exclude all names that contain the token "port"
#
# Tip: To disable counter export put a single token line that fits nothing

# Meta fields are user-defined additional fields of 2 types: aliases and new constant fields.
# - Aliases:
#   add data of field "exact_name" to meta fields of record with new "alias_name".
#   One field can have only one alias.
#   Aliases match only exact names and will appear in data record even if field is disabled by fset.
#   Example:
#     meta_field_alias:exact_name=alias_name
# - Constants:
#   add new field "new_field_name" with constant data string "constant_value" to the meta fields.
#   Names should be unique.
#   Example:
#     meta_field_add:new_field_name=constant_value

# List of available counters:
#
#node_guid
#port_guid
#port_num
#lid
#link_down_counter
#link_error_recovery_counter
#symbol_error_counter
#port_rcv_remote_physical_errors
#port_rcv_errors
#port_xmit_discard
#port_rcv_switch_relay_errors
#excessive_buffer_errors
...
```

The following is the content of `/config/fluent_bit_configs/ufm_enterprise.fset`:

```

# Put your events here

# Usage:
#
# [type_name_1]
# tokens
# [type_name_2]
# tokens
# [type_name_3]
# tokens
# ...

# Tokens are the actual name 'fragments' to be matched
#   port$      # match names ending with token "port"
#   ^port$     # match names starting with token "port"
#   ^port$     # include name that is exact token "port"
#   port+xmit # match names that contain both tokens "port" and "xmit"
#   port-support # match names that contain the token "port" and do not match the "-" token "support"
#   -port      # exclude all names that contain the token "port"

# Meta fields are user-defined additional fields of 2 types: aliases and new constant fields.
# - Aliases:
#   add data of field "exact_name" to meta fields of record with new "alias_name".
#   One field can have only one alias.
#   Aliases match only exact names and will appear in data record even if field is disabled by fset.
#   Example:
#     meta_field_alias:exact_name=alias_name
# - Constants:
#   add new field "new_field_name" with constant data string "constant_value" to the meta fields.
#   Names should be unique.
#   Example:
#     meta_field_add:new_field_name=constant_value

# The next example will export the whole "switch_fan" events and events "CableInfo" filtered with token "port" :
# [switch_fan]
#
# [CableInfo]
# port

# To know which event type names are available use one of these options:
#   1. Check export and find field "type_name"=>"switch_temperature"
#   OR
#   2. Open log file "/tmp/ibd/ibdiagnet2_port_counters.log" and find event types are printed to log:
#
#   ...
#   [info] type [CableInfo] is type of interest
#   [info] type [switch_temperature] is type of interest
#   [info] type [switch_fan] is type of interest
#   [info] type [switch_general] is type of interest
#   ...

# Corner cases:
# 1. Empty fset file will export all events.
# 2. Tokens written above/without [event_type] will be ignored.
# 3. If cannot open fset file, warning will be printed, all event types will be exported.

```

5.3 Quick Start Guide for FluentD

1. Connect to a remote Linux machine via SSH and ensure docker is installed and started on it.

```
[root@r-ufm ~]# sudo service docker start
```

2. Pull FluentD image:

```
[root@r-ufm ~]# sudo docker pull fluentd
```

3. Create a configuration file for fluentd container.

```

[root@r-ufm ~]# export fluentd_dir=/tmp/fluentd
[root@r-ufm ~]# mkdir -p $fluentd_dir
[root@r-ufm ~]# vim $fluentd_dir/config.conf #fill it with next configuration

<source>
  @type forward
  bind 0.0.0.0
  port 24432
</source>

<match ufm_telemetry>
  @type stdout
</match>

```

4. Start fluentd collector container.

```
[root@r-ufm ~]# sudo docker run -it --rm --network host -v $fluentd_dir:/fluentd/etc fluentd -c /fluentd/etc/config.conf -v
```

For more details refer to "[FluentD](#)" on docker hub.

5.4 Data Forwarding

1. Follow the instructions under "[Quick Start Guide for FluentD](#)" to prepare remote host with a running FluentD.
2. Follow the instructions under "[Exporting Data Using Fluent Bit Export](#)" to prepare UFM Telemetry with Fluent Bit export capability and ensure it matches the following configurations:
 - Fluent Bit is enabled (`plugin_env_FLUENT_BIT_EXPORT_ENABLE=1`) in the `launch_ibdiagnet_config.ini` file:

```
[root@r-ufm ~]# grep -a2 fluent /config/launch_ibdiagnet_config.ini
[fluentbit_export]
plugin_env_FLUENT_BIT_EXPORT_ENABLE=1
plugin_env_FLUENT_BIT_CONFIG_DIR=/telemetry.config/fluent_bit_configs
plugin_env_LD_LIBRARY_PATH=/opt/mellanox/collectx/lib
```

- Prepare a `forward.exp` file to send data to remote host where fluentd is running:

```
[root@r-ufm ~]# cat /config/fluent_bit_configs/forward.exp
name=ufm-enterprise
enable=1
plugin_name=forward
host=10.209.36.248 # Remote host IP where fluentd is running
port=24432
plugin_tag_match_pair=ufm_telemetry
```

3. Verify that data is streamed from the CollectX Telemetry plugin and is received on the FluentD collector.

5.5 UFM Telemetry Configuration Script

A script to facilitate the configuration of UFM Telemetry is located under the path `/config/configure_ufm_telemetry_target.py`.

The script is used to set and show sample rate duration, enable and disable streaming capabilities, add, remove, update, enable, disable and review target destinations to receive counters and cable info data, and import filters defined in files to filter streamed data.

```
[root@r-ufm ~]# /config/configure_ufm_telemetry_target.py -h
usage: configure_ufm_telemetry_target.py <command> [<args>]

positional arguments:
  {add-target,show-target,remove-target,enable-target,enable-streaming,disable-target,disable-streaming,modify-target,import-filter-file,disable-filter-file,commands,show-sample-rate,enable-sample-rate}
    Commands
      add-target      Add a telemetry target
      show-target     Show telemetry target(s)
      remove-target   Remove a telemetry target
      enable-target   Enable a telemetry target
      enable-streaming Enable telemetry streaming
      disable-target  Disable a telemetry target
      disable-streaming Disable telemetry streaming
      modify-target   Modify a telemetry target
      import-filter-file Import a telemetry target filter file
      disable-filter-file Disable telemetry target filter file
      commands        Set telemetry sample rate
```

```

show-sample-rate      Show telemetry sample rate
optional arguments:
-h, --help            show this help message and exit
-V, --version         Print version information

```

5.5.1 Controlling Fluent Bit Streaming

Fluent Bit data streaming is disabled by default. You may enable it by using the script argument `enable-streaming` (`disable-streaming` to disable). This changes the value of the `plugin_env_FLUENT_BIT_EXPORT_ENABLE` parameter in the `launch_ibdiagnet_config.ini` file.

```

[root@r-ufm ~]# grep plugin_env_FLUENT_BIT_EXPORT_ENABLE /config/launch_ibdiagnet_config.ini
plugin_env_FLUENT_BIT_EXPORT_ENABLE=0
[root@r-ufm ~]# /config/configure_ufm_telemetry_target.py enable-streaming
[root@r-ufm ~]# grep plugin_env_FLUENT_BIT_EXPORT_ENABLE /config/launch_ibdiagnet_config.ini
plugin_env_FLUENT_BIT_EXPORT_ENABLE=1

```

5.5.2 Controlling Target Destinations

You can add, remove, update, enable, disable and review many target destinations to receive counters and cable info data.

Use the flag `-h` to see the details of any operation.

5.5.2.1 Adding Destination Target

The parameter `add-target` adds and enables a destination target.

```

[root@r-ufm ~]# /config/configure_ufm_telemetry_target.py add-target -h
usage: configure_ufm_telemetry_target.py <command> [<args>] add-target
        [-h] -n <[A-Za-z0-9_-] Name size: 32> -H <IPv4> -p <1-65535> -m
        {extended,standard}

optional arguments:
-h, --help            show this help message and exit
-n <[A-Za-z0-9_-] Name size: 32>, --target-name <[A-Za-z0-9_-] Name size: 32>
                      Target name
-H <IPv4>, --target-host <IPv4>
                      IPv4 address
-p <1-65535>, --target-port <1-65535>
                      Port number
-m {extended,standard}, --target-message-type {extended,standard}

```

For example:

```
[root@r-ufm ~]# /config/configure_ufm_telemetry_target.py add-target --target-name ufm-telemetry --target-host 10.212.145.6 --target-port 24453 -m standard
```

5.5.2.2 Displaying Destination Target Details

The parameter `show-target` displays the details of a destination target.

```

[root@r-ufm ~]#[root@r-ufm ~]# /config/configure_ufm_telemetry_target.py add-target -h
usage: configure_ufm_telemetry_target.py <command> [<args>] add-target
        [-h] -n <[A-Za-z0-9_-] Name size: 32> -H <IPv4> -p <1-65535> -m
        {extended,standard}

optional arguments:
-h, --help            show this help message and exit
-n <[A-Za-z0-9_-] Name size: 32>, --target-name <[A-Za-z0-9_-] Name size: 32>
                      Target name
-H <IPv4>, --target-host <IPv4>

```

```

IPv4 address
-p <1-65535>, --target-port <1-65535>
Port number
-m {extended,standard}, --target-message-type {extended,standard}

```

For example:

```

[root@r-ufm ~]# /config/configure_ufm_telemetry_target.py show-target --target-name ufm-telemetry
Enabled: Yes
Name: ufm-telemetry
Enabled: Yes
Host: 10.212.145.6
Port: 24453
Message Type: Standard

```

5.5.2.3 Disabling Destination Target

The parameter `disable-target` disables a destination target.

```

[root@r-ufm ~]# /config/configure_ufm_telemetry_target.py disable-target -h
usage: configure_ufm_telemetry_target.py <command> [<args>] disable-target
[-h] -n TARGET_NAME

optional arguments:
-h, --help            show this help message and exit
-n TARGET_NAME, --target-name TARGET_NAME

```

For example:

```

[root@r-ufm ~]# /config/configure_ufm_telemetry_target.py disable-target --target-name ufm-telemetry
[root@r-ufm ~]# /config/configure_ufm_telemetry_target.py show-target --target-name ufm-telemetry
Enabled: Yes
Name: ufm-telemetry
Enabled: No
Host: 10.212.145.6
Port: 24453
Message Type: Standard

```

5.5.2.4 Enabling Destination Target

The parameter `enable-target` enables a destination target.

```

[root@r-ufm ~]# /config/configure_ufm_telemetry_target.py enable-target -h
usage: configure_ufm_telemetry_target.py <command> [<args>] enable-target
[-h] -n TARGET_NAME

optional arguments:
-h, --help            show this help message and exit
-n TARGET_NAME, --target-name TARGET_NAME

```

For example:

```

[root@r-ufm ~]# /config/configure_ufm_telemetry_target.py enable-target --target-name ufm-telemetry
[root@r-ufm ~]# /config/configure_ufm_telemetry_target.py show-target --target-name ufm-telemetry
Enabled: Yes
Name: ufm-telemetry
Enabled: Yes
Host: 10.212.145.6
Port: 24453
Message Type: Standard

```

5.5.2.5 Modifying Destination Target

The parameter `modify-target` modifies a destination target.

```

[root@r-ufm ~]# /config/configure_ufm_telemetry_target.py modify-target -h
usage: configure_ufm_telemetry_target.py <command> [<args>] modify-target

```

```

[-h] -n TARGET_NAME [-H <IPv4>] [-p <1-65535>] [-m {extended,standard}]

optional arguments:
-h, --help            show this help message and exit
-n TARGET_NAME, --target-name TARGET_NAME
-H <IPv4>, --target-host <IPv4>
                  IPv4 address
-p <1-65535>, --target-port <1-65535>
                  Port number
-m {extended,standard}, --target-message-type {extended,standard}

```

For example:

```

[root@r-ufm ~]# /config/configure_ufm_telemetry_target.py modify-target --target-name ufm-telemetry --target-host 10.212.145.7 --target-port 24455 -m standard
[root@r-ufm ~]# /config/configure_ufm_telemetry_target.py show-target --target-name ufm-telemetry
Enabled: Yes
Name: ufm-telemetry
Enabled: Yes
Host: 10.212.145.7
Port: 24455
Message Type: Standard

```

5.5.2.6 Removing Destination Target

The parameter `remove-target` removes a destination target.

```

[root@r-ufm ~]# /config/configure_ufm_telemetry_target.py remove-target -h
usage: configure_ufm_telemetry_target.py <command> [<args>] remove-target
[-h] -n TARGET_NAME

optional arguments:
-h, --help            show this help message and exit
-n TARGET_NAME, --target-name TARGET_NAME

```

For example:

```

[root@r-ufm ~]# /config/configure_ufm_telemetry_target.py remove-target --target-name ufm-telemetry
[root@r-ufm ~]# /config/configure_ufm_telemetry_target.py show-target --target-name ufm-telemetry
Enabled: Yes
Target ufm-telemetry is missing. Please add it first.

```

5.5.3 Data Filtration

The `configure_ufm_telemetry_target.py` script allows users to import filter files to enable filtering streamed data and to disable filter options.

5.5.3.1 Enabling Data Filtration

To enable filtration of the streamed counters and cable info data, users must create a file containing the appropriate RegEx patterns (one pattern per line to extract the required parameters data).

```

[root@r-ufm ~]# cat ~/counters_filter
lm_counter
Errors

```

Then they must import the filter file to a destination, specifying the type of data (counters or cable info) using the parameter `import-filter-file`.

```

[root@r-ufm ~]# /config/configure_ufm_telemetry_target.py import-filter-file -h
usage: configure_ufm_telemetry_target.py <command> [<args>] import-filter-file
[-h] -n TARGET_NAME -t {counters,fields} -f FILE_PATH

optional arguments:
-h, --help            show this help message and exit

```

```
-n TARGET_NAME, --target-name TARGET_NAME
-t {counters,fields}, --target-filter-type {counters,fields}
-f FILE_PATH, --file-path FILE_PATH
```

For example, to enable filtering streamed data and create filters:

```
[root@r-ufm ~]# /config/configure_ufm_telemetry_target.py import-filter-file --target-name ufm-telemetry --target-
filter-type counters --file-path ~/counters_filter
```

On the target destination side, users will receive all the counters include one of texts (lm_counterm Errors).

5.5.3.2 Disabling Data Filtration

The parameter `disable-filter-file` disables an imported filtering file.

```
[root@r-ufm ~]# /config/configure_ufm_telemetry_target.py disable-filter-file -h
usage: configure_ufm_telemetry_target.py <command> [<args>] disable-filter-file
[-h] -n TARGET_NAME -t {counters,fields}

optional arguments:
-h, --help            show this help message and exit
-n TARGET_NAME, --target-name TARGET_NAME
-t {counters,fields}, --target-filter-type {counters,fields}
```

For example:

```
[root@r-ufm ~]# /config/configure_ufm_telemetry_target.py disable-filter-file --target-name ufm-telemetry --target-
filter-type counters
```

On the target destination side, users will receive all the counters without filtering.

6 Settings and Configuration

Inside the container, the directory `/config` contains the configuration files for the NVIDIA® UFM® Telemetry application. The file `launch_ibdiagnet_config.ini` is the main configuration file.

The basic configurations of `launch_ibdiagnet_config.ini` are listed in the following table.

Section	Key	Type	Default Value	Description
ibdiagnet	ibdiagnet_enabled	bool	true	Enable/disable run ibdiagnet process
	data_dir	String	/data	Directory in which UFM Telemetry data is placed
	ibdiag_output_dir	String	/tmp/ibd	Directory in which ibdiagnet places files
	sample_rate	Int	-	Frequency of collecting ports counters data
	hca	String	mlx5_2	Card to use. Can provide a comma-separated list of cards for local high availability
	force_hca	bool	false	Skip hca state check
	app_name	String	/opt/collectx/bin/ibdiagnet	Allow user to specify full path of the ibdiagnet application if necessary
	topology_mode	String	discover	Topology policy
	topology_discovery_factor	Int	0	Every "n" iterations, do discovery, otherwise, use result from last run if 0 or 1
	m_key	int	-	Set the m_key used by ibdiagnet for data collection
Retention	retention_enabled	bool	true	Enable/disable retention service
	retention_interval	time	1d	Interval to wait before running the retention process
	retention_age	time	100d	Period to reserve the collected data
compression	compression_enable	bool	true	Enable/disable compression service
	compression_interval	time	6h	Interval to wait before running the compression service
	compression_age	time	12h	Period to reserve the compressed data
cable_info	cable_info_schedule	CSV	-	weekday/hr:min,hr:hm Time to collect cable info data

6.1 Log File Rotation

UFM telemetry log file “ `ibdiagnet2_port_counters.log` ” size is monitored by log rotation mechanism. This is highly relevant for cases of long execution time and/or high verbosity, where the number of logs can get excessively big.

To disable log rotation, verify that the following flag is set to 0 (default is 1):

```
plugin_env_CLX_LOG_ROTATE_ENABLED
```

To change the number of rotated files, set the following flag (default is 3):

```
plugin_env_CLX_LOG_ROTATE_NUM_FILES
```

To change the rotation’s threshold, set the following flag (default is 100M), use [K|M|G] as units:

```
plugin_env_CLX_LOG_ROTATE_SIZE
```

There are three optional rotation methods, used in the following order:

1. `rotatelogs` - If this executable exists, it will be used for logs rotation, and the rotated files name will differ by index suffix.
2. `logrotate` - If this executable exists, it will be used for logs rotation, and the rotated files name will differ by timestamp suffix.
3. manual rotation - In case both executables are not available, UFM telemetry will manually rotate 2 log files. The older log file will have “ `.bck` ”

To skip options, the following flag set the executables to use (default is “`rotatelogs,logrotate`”):

```
plugin_env_CLX_LOG_ROTATE_APP
```

6.2 Port Counters

The table below outlines the supported configurations for enabling section collection.

To include a register for collection, certain configurations need to be added, some removed, and some may depend on other registers. Please refer to the table below for instructions:

Please note that the ‘arg’ key names may differ.

Register / Page name	Configurations to be Applied	Configurations to be Removed	Dependencies
SLRIP	<code>arg_slrip==>get_phy_info</code> <code>--enabled_regs slrip</code> <code>plugin_env_CLX_EXPORT_AP</code> <code>I_SKIP_SLRIP=0</code>		

Register / Page name	Configurations to be Applied	Configurations to be Removed	Dependencies
SLRP	<code>arg_slrp==>get_phy_info --enabled_regs slrp plugin_env_CLX_EXPORT_AP I_SKIP_SLRP=0</code>		
SLRG	<code>arg_slrq==>get_phy_info --enabled_regs slrq plugin_env_CLX_EXPORT_AP I_SKIP_SLRG=0</code>		
PTYs	<code>arg_ptys==>get_phy_info --enabled_regs ptys plugin_env_CLX_EXPORT_AP I_SKIP_PTYS=0</code>		
PPHCR	<code>arg_pphcr==>get_phy_info --enabled_regs pphcr plugin_env_CLX_EXPORT_AP I_SKIP_PPHCR=0</code>		
SLSIR	<code>arg_slsir==>get_phy_info --enabled_regs slsir plugin_env_CLX_EXPORT_AP I_SKIP_SLSIR=0</code>		
SLTP	<code>arg_sltp==>get_phy_info --enabled_regs sltp plugin_env_CLX_EXPORT_AP I_SKIP_SLTP=0</code>		
PMDR	<code>arg_pmdr==>get_phy_info --enabled_regs pmdr plugin_env_CLX_EXPORT_AP I_SKIP_PMDR=0</code>		
PPLL	<code>arg_ppll==>get_phy_info --enabled_regs ppll plugin_env_CLX_EXPORT_AP I_SKIP_PPLL=0</code>		
SLLM	<code>arg_sllm==>get_phy_info --enabled_regs sllm plugin_env_CLX_EXPORT_AP I_SKIP_SLLM=0</code>		

Register / Page name	Configurations to be Applied	Configurations to be Removed	Dependencies
PHY BER Params	<pre>arg_phy_ber_params--- get_phy_info -- enabled_regs ppbmp plugin_env_CLX_EXPORT_AP I_SKIP_PHY_BER_PARAMS=0</pre>		
MRCS	<pre>arg_mracs---get_phy_info --enabled_regs mracs plugin_env_CLX_EXPORT_AP I_SKIP_MRCS=0</pre>		
PEMI Module Samples	<pre>arg_pemi_module_samples= --get_phy_info -- enabled_regs pemi_module_s plugin_env_CLX_EXPORT_AP I_SKIP_PEMI_MODULE_SAMPLE S=0</pre>		
PEMI SNR Samples	<pre>arg_pemi_snr_samples--- get_phy_info -- enabled_regs pemi_snr_s plugin_env_CLX_EXPORT_AP I_SKIP_PEMI_SNR_SAMPLES=0</pre>		
PEMI Laser Samples	<pre>arg_pemi_laser_samples--- -get_phy_info -- enabled_regs pemi_laser_s plugin_env_CLX_EXPORT_AP I_SKIP_PEMI_LASER_SAMPLES =0</pre>		
PEMI Pam4 Samples	<pre>arg_pemi_pam4_samples--- get_phy_info -- enabled_regs pemi_pam4_s plugin_env_CLX_EXPORT_AP I_SKIP_PEMI_PAM4_SAMPLES=0</pre>		
PEMI Pre FEC BER Samples	<pre>arg_pemi_pre_fec_ber_samples---get_phy_info -- enabled_regs pemi_ber_s plugin_env_CLX_EXPORT_AP I_SKIP_PEMI_PRE_FEC_BER_SAMPLES=0</pre>		

Register / Page name	Configurations to be Applied	Configurations to be Removed	Dependencies
PEMI Pre FEC BER Properties	arg_pemi_pre_fec_ber_properties==get_phy_info -- enabled_regs pemi_ber_plugin_env_CLX_EXPORT_AP I_SKIP_PEMI_PRE_FEC_BER_PROPERTIES=0		
PEMI Ferc Samples	arg_pemi_ferc_samples==get_phy_info -- enabled_regs pemi_ferc_plugin_env_CLX_EXPORT_AP I_SKIP_PEMI_FERC_SAMPLES=0		
PHY Counters	arg_phy_cntrs==get_phy_info -- enabled_regs dd_ppcnt_plc_plugin_env_CLX_EXPORT_AP I_SKIP_PHY_CNTRS=0		
PHY Statistics	arg_phy_stat==get_phy_info -- enabled_regs dd_ppcnt_plsc_plugin_env_CLX_EXPORT_AP I_SKIP_PHY_STAT=0		
PHY InfiniBand General Counters	arg_phy_ib_general_cntrs==get_phy_info -- enabled_regs dd_ppcnt_gen_counters_plugin_env_CLX_EXPORT_AP I_SKIP_PHY_IB_GENERAL_CNT_RS=0		
Histograms	arg_hist==get_phy_info -- enabled_regs dd_ppcnt_rsfec_plugin_env_CLX_EXPORT_AP I_SKIP_HIST=0		
Troubleshoot	arg_troubleshoot==get_phy_info -- enabled_regs dd_paddr_tpi_plugin_env_CLX_EXPORT_AP I_SKIP_TROUBLESHOOT=0		

Register / Page name	Configurations to be Applied	Configurations to be Removed	Dependencies
Operation Info	<pre>arg_operation_info--- get_phy_info -- enabled_regs dd_pddr_op plugin_env_CLX_EXPORT_AP I_SKIP_OPERATION_INFO=0</pre>		
Link Down Info	<pre>arg_link_down_info--- get_phy_info -- enabled_regs dd_pddr_ldown plugin_env_CLX_EXPORT_AP I_SKIP_LINK_DOWN_INFO=0</pre>		
Link Up Info	<pre>arg_link_up_info--- get_phy_info -- enabled_regs dd_pddr_lup plugin_env_CLX_EXPORT_AP I_SKIP_LINK_UP_INFO=0</pre>		
PLR	<pre>arg_plr---get_phy_info --enabled_regs dd_ppcnt_plr plugin_env_CLX_EXPORT_AP I_SKIP_PLR=0</pre>		
Port VL	<pre>arg_port_vl=- per_slvl_cntrs plugin_env_CLX_EXPORT_AP I_SKIP_PORT_VL=0</pre>		
MLNX Counters Page0	<pre>arg_mlnx_counters_page0= -sc plugin_env_CLX_EXPORT_AP I_SKIP_MLNX_COUNTERS_PAGE 0=0</pre>		
MLNX Counters Page1	<pre>arg_mlnx_counters_page1= -sc plugin_env_CLX_EXPORT_AP I_SKIP_MLNX_COUNTERS_PAGE 1=0</pre>		
MLNX Counters Page255	<pre>arg_mlnx_counters_page25 5=-sc plugin_env_CLX_EXPORT_AP I_SKIP_MLNX_COUNTERS_PAGE 255=0</pre>		

Register / Page name	Configurations to be Applied	Configurations to be Removed	Dependencies
Sharp PM Counters	arg_sharp_pm_counters=-- sharp --sharp_opt dsc plugin_env_CLX_EXPORT_AP I_SKIP_SHARP_PM_COUNTERS=0		
General Info	plugin_env_CLX_EXPORT_AP I_SKIP_GENERAL_INFO=0	arg_general_info=-- skip_nodes_info	
Device Temperature	plugin_env_CLX_EXPORT_AP I_SKIP_DEV_TEMP=0	arg_dev_temp=--skip temp_sensing	
Port Counters	plugin_env_CLX_EXPORT_AP I_SKIP_PORT_COUNTERS=0		
Port Counters Extended	plugin_env_CLX_EXPORT_AP I_SKIP_PORT_COUNTERS_EXTE NDDED=0		
Extended Speeds Counters	plugin_env_CLX_EXPORT_AP I_SKIP_EXTENDED_SPEEDS_CO UNTERS=0		
LLR Statistics	plugin_env_CLX_EXPORT_AP I_SKIP_LLRL_STATISTICS=0		
Port Rcv Error Details	plugin_env_CLX_EXPORT_AP I_SKIP_PORT_RCV_ERROR_DET AILS=0		
Port Xmit Discard Details	plugin_env_CLX_EXPORT_AP I_SKIP_PORT_XMIT_DISCARD_ DETAILS=0		
Port RN Counters	plugin_env_CLX_EXPORT_AP I_SKIP_RN_COUNTERS=0		
Port HBF Counters	plugin_env_CLX_EXPORT_AP I_SKIP_HBF_COUNTERS=0		
Fast Recovery Counters	plugin_env_CLX_EXPORT_AP I_SKIP_PORT_FAST_RECOVERY =0		
Port Hierarchy	plugin_env_CLX_EXPORT_AP I_SKIP_PORT_HIERARCHY=0		
Link Partner	plugin_env_CLX_EXPORT_AP I_SKIP_LINK_PARTNER_EXT=0		
Ports	plugin_env_CLX_EXPORT_AP I_SKIP_PORTS=0		Operation Info

Register / Page name	Configurations to be Applied	Configurations to be Removed	Dependencies
Calculated Info	plugin_env_CLX_EXPORT_AP I_SKIP_CALC_INFO=0		Port Counters Extended, Ports, Operation Info

6.3 Events

The info below outlines the supported configurations for enabling section collection.

6.3.1 Enable PPCC

```
plugin_env_CLX_EXPORT_API_DISABLE_PPCCINFO
```

The following events are created:

```
ppcc_algo_config, ppcc_algo_config_params, ppcc_algo_config_support,  
ppcc_algo_counters
```

6.3.2 Switch Power Sensors Data

To enable Switch power sensors, ensure that the following line is added and not commented:

```
arg_x= --get_phy_info --enabled_reg mvcr # x should be replaced with the next available index!
```

Verify the following line does not exist / is set to 0:

```
plugin_env_CLX_EXPORT_API_DISABLE_SWITCHINFO=0
```

6.3.3 Switch Power Supplies Data

To enable switch power supplies, ensure that the following line is added and not commented:

```
arg_x= --get_phy_info --enabled_reg msps # x should be replaced with the next available index!
```

Verify the following line does not exist / is set to 0:

```
plugin_env_CLX_EXPORT_API_DISABLE_SWITCHINFO=0
```

6.3.4 Managed Switch Data Collection

Prerequisite: Access to UFM that is running the sysinfo plugin. The following configs are mandatory to enable the collection.

To enables the feature, run:

```
plugin_env_CLX_EXPORT_API_DISABLE_MANAGED_SWITCHINFO=0
```

UFM endpoint:

```
plugin_env_MANAGED_SWITCH_DATA_EP=https://localhost/ufmRest/plugin/sysinfo/query
```

UFM token:

```
plugin_env_CLX_UMF_TOKEN=YWRtaW46MTIzNDU2
```

The UFM Telemetry server endpoint must be the same as the `PROMETHEUS_ENDPOINT`

```
plugin_env_CLX_EXPORT_API_MANAGED_SWITCH_CB_EP=http://localhost:1234/management/key_value
```

The following configs are optional:

- The list of managed switches to sample, the default are all the managed switches on the fabric, defined by the sysinfo plugin:

```
plugin_env_CLX_EXPORT_API_MANAGED_SWITCH_LIST=11.222.33.44,11.333.444.55
```

- `sample_rate` of `managed_switches(seconds)` should not be set faster than switch collection sample rate, default is 10 minutes.

```
plugin_env_CLX_EXPORT_API_MANAGED_SWITCH_INTERVAL=600
```

6.3.5 NVLink Info

The following configuration should be applied:

*the arg key name may differ

```
arg_nvlink_info=--nvlink  
plugin_env_CLX_EXPORT_API_SKIP_NVLINKINFO=0
```

7 Prometheus Endpoint Support

7.1 Prometheus Endpoint

UFM Telemetry can expose an http or https endpoint to allow simple and effective integration with monitoring systems that work in poll mode and support Prometheus, CSV, or JSON data formats. The endpoint provides only the last data sample. The user cannot obtain statistics for time points in the past.

7.2 Supported Formats

An http endpoint provides data in Prometheus format by default. It also supports JSON and CSV formats. The user can request the desired format using a URL prefix, as shown in the table below.

Data Format	URL Prefix
Prometheus	-
JSON	/json
CSV	/csv

7.3 Data Filtering

An http endpoint can provide all sampled data using the default `/metrics` URL. The filtering functionality described in the [Cset/Fset Filtering](#) section is also supported. To use it place `<name>.cset` or `<name>.fset` file in appropriate folders. This folder should be stated in configuration file. See section "[Configuring Data Polling Endpoint](#)" for more details.

The Extended counter set filtering, as described below, presents an alternative approach to filtering functionality by enabling counters and field selection.

A filter file name is included in the URL to request that the data be filtered through the particular `.cset` / `.fset` / `.xcset` file the user intends. For example, if there are two filter files named `name1.cset` and `name2.cset`, then URLs `/name1` (or `/cset/name1`) and `/name2` (or `/cset/name2`) can be used to get filtered output described in these files accordingly.

The URL prefixes `/cset`, `/fset` and `/xcet` can also be used to specify which filter file is meant.

URL	File Extension	Folder Parameter in Configuration File	Note
<code>/cset</code>	<code>*.cset</code>	<code>plugin_env_PROMETHEUS_CSET_DIR</code>	If the <code>cset</code> folder is not explicitly specified in the configuration file, then the <code>cset</code> directory is set the same as the <code>fset</code> directory.
<code>/fset</code>	<code>*.fset</code>	<code>plugin_env_PROMETHEUS_FSET_DIR</code>	If the <code>fset</code> folder is not explicitly specified in the configuration file, then the <code>fset</code> directory is set the same as the <code>cset</code> directory.

URL	File Extension	Folder Parameter in Configuration File	Note
/xcset	*.xcse	plugin_env_PROMETHEUS_XCSET_DIR	If the <code>xcset</code> folder is not explicitly specified in the configuration file, then the <code>xcset</code> directory is set the same as the <code>fset</code> directory.

If a URL prefix is not specified, then the filter file will be searched under both cset and fset folders. If they both have files with the same names, then both filters will be applied.

7.3.1 Extended Counter Set Filtering

The http server provides an optional Extended counter set (`xcset`) selection mechanism in addition to the counter set (`cset`) and field set (`fset`) filtering. The Extended Counterset allows the user to generate an output record which contains data from both ‘counters’ and ‘event’ data records with the same index, which in the context of UFM Telemetry is generally the guid/port_num. To define an extended counter set, a file or group of files with the `.xcset` extension must be placed in its designated directory or adjacent to existing field or counter sets.

Each line of the file may contain:

- Selection of a counter with an optional alias in the format “`counter[=alias]`”
- Selection of a type’s field with an optional alias in the format “`type.field[=alias]`”
- Reference to another file to be included “`file.xcset`”

Extended counter set files are searched for in the same directory as the source xcset.

Aliases are not mandatory, but if provided, they are used to name the selected counter or field in the output. Empty lines and comments that begin with the “#” sign are disregarded.

7.4 URL Prefixes Priority

URL prefixes can be used to manipulate data output. It is important to use the prefixes in the correct order as they have assigned priorities. The table below shows URL prefixes priority assignments with examples:

Priority	Prefix	Link Examples	Description
1	<code>/labels</code>	<code>/labels/metrics</code> , <code>/metrics</code>	Used to show labels from metadata files
2	<code>/json</code> , <code>/csv</code>	<code>/json/metrics</code> , <code>/csv/metrics</code> , <code>/labels/json/metrics</code> , <code>/labels/csv/metrics</code>	Used to specify output format

Priority	Prefix	Link Examples	Description
3	/cset, /fset, /xcset	/cset/filter1, /fset/filter2, /labels/cset/filter1, /labels/fset/filter2, /json/cset/filter1, /json/fset/filter2, /csv/cset/filter1, /csv/fset/filter2, /csv/xcset/ib, /labels/json/cset/ filter1, /labels/json/fset/ filter2, /labels/csv/cset/ filter1, /labels/csv/fset/ filter2	Used to specify which type of filer file should be applied

7.5 Configuring Data Polling Endpoint

To configure the Prometheus endpoint, the keys listed below need to be set in the `launch_ibdiagnet_config.ini` file.

```
plugin_env_PROMETHEUS_ENDPOINT http://0.0.0.0:9100
plugin_env_PROMETHEUS_PROXY_ENDPOINT_PORT 9200
plugin_env_PROMETHEUS_INDEXES port_num
plugin_env_PROMETHEUS_FSET_INDEXES port,lid,guid,[CableInfo]^port_guid,^Port$ /config/prometheus_configs/cset
plugin_env_PROMETHEUS_CSET_DIR ...
...
```

There are several options related to configuring the HTTP polling endpoint. The key `plugin_env_PROMETHEUS_ENDPOINT` is used to configure the IP interface for endpoint binding. The “0.0.0.0” part in the setting above means that any of the host’s valid IP addresses can be used. Note that the user can also specify the host’s IP address explicitly.

The `plugin_env_PROMETHEUS_ENDPOINT` key also configures the data transport. For regular HTTP, prefix to `http`. To send over a TLS connection, set the prefix to `https`, set the above mandatory parameters (keys), and select the existing security keys as follows.

A DH (key exchange protoon) file can also be specified if needed as follows:

```
plugin_env_CLX_SSL_DH_FILE=/certs/dh.pem
```

To use custom labels for Prometheus statistics, a metadata file is used. For details about labels and label file format, see sections “[Prometheus Labels](#)” and “[Prometheus Label Generation](#)”.

There are several options that allow configuring metadata. The file containing the labels used in Prometheus generation is set as follows:

```
plugin_env_CLX_METADATA_FILE=/config/labels.txt
```

The user can create the metadata file upon system setup or use a script to generate it automatically via script, using the following parameter:

```
plugin_env_CLX_METADATA_COMMAND=/opt/mellanox/collectx/telem/bin/gen_metadata --fabric compute --file /var/log/ibdiagnet2.ibnetdiscover --output /config/labels.txt
```

In the above example, the script generates metadata from `/var/log/ibdiagnet2.ibnetdiscover`. If the user wishes to create the label file manually, the above option should be commented out to prevent periodic overwriting of the content of the metadata file.

By default, the Prometheus endpoint provides statistics with the collection timestamps. The user can decide whether counter values will be passed with or without timestamps by setting the `plugin_env_PROMETHEUS_SHOW_TIMESTAMPS` parameter to T (true) or F (false), respectively. For example, to send counter values without timestamps, set the parameter as follows:

```
plugin_env_PROMETHEUS_SHOW_TIMESTAMPS=F
```

To use data filters folders with counter set, field sets, and extended counter sets, the directories where the files are stored should be configured as follows:

```
plugin_env_PROMETHEUS_CSET_DIR=/telemetry.config/prometheus_configs/cset  
plugin_env_PROMETHEUS_FSET_DIR=/telemetry.config/prometheus_configs/fset  
plugin_env_PROMETHEUS_XCSET_DIR=/telemetry.config/prometheus_configs/xcset
```

Any parameters not explicitly documented should not be changed and should be considered read-only.

7.6 Prometheus Labels

For use cases such as UFM Enterprise or UFM Cyber AI where the network topology is known, a human-readable name can be presented based on the GUID.

```
# TYPE PortXmitDataExtended counter  
# TYPE PortXmitPktsExtended counter  
PortXmitDataExtended(source="0x0002c90300f172a0", node_guid="2c90300f172a0", port_guid="2c90300f172a2",  
port_num="2") 85554128244 1628683905941  
PortXmitPktsExtended(source="0x0002c90300f172a0", node_guid="2c90300f172a0", port_guid="2c90300f172a2",  
port_num="2") 1188251785 1628683905941
```

For integration with third-party applications, labels which are more human-readable may be generated using a labels metadata file, as described below.

7.7 Prometheus Label Generation

To generate custom labels, a file containing key-value pairs is used. When the keys are matched, the key-value pairs added to the Prometheus labels are generated.

The following is an example of the format of a labels metadata file:

```

ec0d9a0300b41a50_36|port_id|ec0d9a0300b41a50_36|device_name|SwitchIB Mellanox Technologies|device_type|switch|
fabric|compute|hostname||node_desc||level|leaf|peer_level|server
ec0d9a0300b41a50_37|port_id|ec0d9a0300b41a50_37|device_name|SwitchIB Mellanox Technologies|device_type|switch|
fabric|compute|hostname||node_desc||level|leaf|peer_level|
ec0d9a0300b41a58_1|port_id|ec0d9a0300b41a58_1|device_name||device_type|switch|fabric|compute|hostname|aggregation|
node_desc|aggregation_node|level||peer_level||leaf
98039b0300640b92_1|port_id|98039b0300640b92_1|device_name||device_type|host|fabric|compute|hostname|agx-1|
node_desc|agx-1|mlx5_0|level|server|peer_level||leaf
98039b0300640c22_1|port_id|98039b0300640c22_1|device_name||device_type|host|fabric|compute|hostname|agx-2|
node_desc|agx-2|mlx5_0|level|server|peer_level||leaf
0002c90300f172a0_2|port_id|0002c90300f172a0_2|device_name||device_type|host|fabric|compute|hostname|agx-3|
node_desc|agx-3|mlx4_0|level|server|peer_level||leaf
98039b0300640b9a_1|port_id|98039b0300640b9a_1|device_name||device_type|host|fabric|compute|hostname|agx-3|
node_desc|agx-3|mlx5_0|level|server|peer_level||leaf

```

The following is an example of the generated Prometheus output:

```

# TYPE infiniband_port_xmit_data_bytes counter
# TYPE infiniband_port_rcv_data_bytes counter
# TYPE infiniband_link_error_recovery_events counter
# TYPE infiniband_link_downed_events counter
# TYPE infiniband_cbw gauge
infiniband_port_xmit_data_bytes      {port_id="0002c90300f172a0_2", ADDITIONAL_LABELS} 82218360540 1628602711924
infiniband_port_rcv_data_bytes      {port_id="0002c90300f172a0_2", ADDITIONAL_LABELS} 82218429458 1628602711924
infiniband_link_error_recovery_events {port_id="0002c90300f172a0_2", ADDITIONAL_LABELS} 0 1628602711924
infiniband_link_downed_events       {port_id="0002c90300f172a0_2", ADDITIONAL_LABELS} 0 1628602711924
infiniband_cbw                      {port_id="0002c90300f172a0_2", ADDITIONAL_LABELS} 0 1628602711924

where ADDITIONAL_LABELS include:
  hostname="agx-3"
  node_desc="agx-3 mlx5_0"
  device_name=""
  device_type="host"
  fabric="compute"
  level="server"
  peer_level="leaf"

```

To enable this functionality, the following additional keys need to be configured:

```

plugin_env_CLX_EXPORT_API_IBNETDISCOVER_RUN_ONCE 1    # Without this, the gen_metadata.py script cannot generate
the human readable names, nor the level and peer_level.
plugin_env_CLX_METADATA_FILE /path/to/labels/file
plugin_env_CLX_METADATA_COMMAND "python3 /opt/mellanox/collectx/telem/bin/gen_metadata.py --fabric compute --
file /var/log/ibdiagnet2.ibnetdiscover -o /path/to/labels/file"

```

To test, the `curl` command can be used as follows:

```

[root@jazz11 ~]# curl -s IP_ADDR_OF_HOST:9100/metrics |egrep "xmit|rcv" | tail
port_xmit_discard{device_name="",device_type="host",fabric="compute",hostname="jazz32",level="server",node_desc="ja
zz32 mlx5_2",peer_level="leaf",port_id="ec0d9a0300c04a54_1"} 0 1629194120043
port_rcv_switch_relay_errors{device_name="",device_type="host",fabric="compute",hostname="jazz32",level="server",no
de_desc="jazz32 mlx5_2",peer_level="leaf",port_id="ec0d9a0300c04a54_1"} 0 1629194120043
port_rcv_constraint_errors{device_name="",device_type="host",fabric="compute",hostname="jazz32",level="server",node
_desc="jazz32 mlx5_2",peer_level="leaf",port_id="ec0d9a0300c04a54_1"} 0 1629194120043
port_xmit_constraint_errors{device_name="",device_type="host",fabric="compute",hostname="jazz32",level="server",nod
e_desc="jazz32 mlx5_2",peer_level="leaf",port_id="ec0d9a0300c04a54_1"} 0 1629194120043

```

8 Distributed Telemetry - Switch Telemetry Agent


8.1 Overview

Distributed Telemetry (DT) is UFM Telemetry mode when the whole fabric telemetry is sampled from managed switches and hosts.

- Managed switch samples itself and hosts connected directly to it
- Each managed switch TI reports to one of several host TIs via MADs
- If a fabric GUID/Port can be sampled, but not sampled by a switch, host TI will sample it.

The whole process is orchestrated by [UFM Telemetry Manager \(UTM\)](#) on the top load balancer. Switch telemetry is organized as a docker container (Switch Agent) with a telemetry package inside.

Figure 1: Distributed Telemetry components relation



8.1.1 Terminology

Switch Telemetry docker image contains:

- Switch Agent is an HTTP server running inside of the container.
- Switch Telemetry Instance (Switch TI) that can be started or stopped within the container

To deploy/remove Switch Agent = to deploy/remove Switch Telemetry Container.

8.2 Deployment

The deployment process is described in [UFM Telemetry Manager \(UTM\)](#).

Switch Telemetry docker image is being docker pulled by the deployment script.

After preparing the setup enable Distributed Telemetry in `utm_config.ini`, as explained in the chapter [Configuration File](#).

8.2.1 Running Distributed telemetry via HTTP API

To get help for all HTTP API endpoints use `/help` endpoint:

```
UTM HTTP API help
```

```
curl -s http://127.0.0.1:8888/help
```

UTM HTTP API allows users to:

- get the status of Switch Agent/Telemetry instances
- deploy/remove Switch Agent containers
- start/stop Switch Telemetry inside of deployed containers
- set switches IP list to be periodically monitored.

Recommended flow to work with Distributed Telemetry:

- Deploy:
 - Check the switches status and find IP list to work with
 - Set monitoring switch list and deploy Switch Agents to this list
 - Start switch Tls
- Cleanup:
 - Stop switch Tls
 - Remove Switch Agents
 - Check switches status

Detailed instructions for Switch Agent and Switch Telemetry are listed in the following subsections.

8.2.1.1 API for Switch Agents

- Get the status of the managed switches in JSON format.

```
get managed switches status
```

```
# all managed switches
curl -s http://127.0.0.1:8888/managed_switches_status

# managed switches set to periodic monitoring only:
curl -s http://127.0.0.1:8888/managed_switches_status?monitored_only=1
```

`/status` endpoint provides JSON object per managed switch, which shows basic info about the switch, status of Switch Agent, and Switch Telemetry (If Switch Agent is installed to the switch).

- Set switch IP list for periodic monitoring. Monitoring updates switch information for `/managed_switches_status` endpoint.

```
set monitoring IP list

# monitor only IP1,IP2:
curl -s http://127.0.0.1:8888/switch_mon_list?ip_list=IP1,IP2

# monitor all managed switches
curl -s http://127.0.0.1:8888/switch_mon_list?ip_list=all
```

- Deploy switch agents to a list of managed switches.

```
deploy Switch Agents

# deploy to all the managed switches:
curl -s http://127.0.0.1:8888/deploy_switch_agents?ip_list=all

# deploy to switches with IPs IP1 and IP2:
curl -s http://127.0.0.1:8888/deploy_switch_agents?ip_list=IP1,IP2
```

- Remove switch agents from a list of managed switches

```
remove Switch Agents

# deploy to all the managed switches:
curl -s http://127.0.0.1:8888/remove_switch_agents?ip_list=all

# deploy to switches with IPs IP1 and IP2:
curl -s http://127.0.0.1:8888/remove_switch_agents?ip_list=IP1,IP2
```

8.2.1.2 API for Switch Telemetry:

- Start switch telemetry. Note at least one managed host TI should run.

```
start Switch Telemetry

# for all running Switch Agents
curl -s http://127.0.0.1:8888/start_switch_telemetry

# at a specific switch IP:
curl -s http://127.0.0.1:8888/start_switch_telemetry?ip=IP1
```

- Stop switch telemetry:

```
stop Switch Telemetry

# for all running Switch Agents
curl -s http://127.0.0.1:8888/stop_switch_telemetry

at a specific switch IP:
curl -s http://127.0.0.1:8888/stop_switch_telemetry?ip=IP1
```

9 Supported Telemetry Fields

9.1 Ports Counters Info

The table below lists the names of Registers/Pages supported by telemetry, along with their respective field lists.

Register / Page Name	Field List
SLRP	ffe_tap[0-8]_ib[0-3]_lane[0-3] ffe_tap_en_ib[0-3]_lane[0-3] mixer_offset[0-1]_ib[0-3]_lane[0-3] saved[0-1]_mixer_offset0_ib[0-3]_lane[0-3] saved[0-1]_sel_enc0_ib[0-3]_lane[0-3] sel_enc[0-2]_ib[0-3]_lane[0-3] slrip_status_lane[0-3]
SLRP	crnt_bgn_offset_n[0-1]_lane[0-3] crnt_bgn_offset_p[0-1]_lane[0-3] dp_sel_lane[0-3] gctrl_bin_bgn[0-1]_n_lane[0-3] gctrl_bin_bgn[0-1]_p_lane[0-3] mixer_offset_down_lane[0-3] mixer_offset_eye_scan_lane[0-3] mixer_offset_up_lane[0-3] sel_amp_mixer_biasgen_down_lane[0-3] sel_amp_mixer_biasgen_eo_lane[0-3] sel_amp_mixer_biasgen_mid_lane[0-3] sel_amp_mixer_biasgen_up_lane[0-3] sel_bias2ctle_lane[0-3] sel_bias_en_[0-6]_lane[0-3] sel_digital_gctrl_lane[0-3] sel_enc_lane[0-3] sel_gctrln_en_[0-6]_lane[0-3] sel_gctrlp_en_[0-6]_lane[0-3] sel_ref_in_mixer_biasgen_down_lane[0-3] sel_ref_in_mixer_biasgen_eo_lane[0-3] sel_ref_in_mixer_biasgen_mid_lane[0-3] sel_ref_in_mixer_biasgen_up_lane[0-3] sel_ref_out_mixer_biasgen_down_lane[0-3] sel_ref_out_mixer_biasgen_eo_lane[0-3] sel_ref_out_mixer_biasgen_mid_lane[0-3] sel_ref_out_mixer_biasgen_up_lane[0-3] selgc_ref_op[0-1]_alev_ctle_lane[0-3]

Register / Page Name	Field List
SLRG	Lane[0-3]Grade dn_eye_grade_lane[0-3] fom_measurment_lane[0-3] fom_mode_lane[0-3] grade_lane_speed_lane[0-3] grade_version_lane[0-3] height_eo_neg_low_lane[0-3] height_eo_neg_mid_lane[0-3] height_eo_neg_up_lane[0-3] height_eo_pos_low_lane[0-3] height_eo_pos_mid_lane[0-3] height_eo_pos_up_lane[0-3] initial_fom_lane[0-3] last_fom_lane[0-3] lower_eye_lane[0-3] meas_done_lane[0-3] mid_eye_grade_lane[0-3] mid_eye_lane[0-3] phase_eo_neg_low_lane[0-3] phase_eo_neg_mid_lane[0-3] phase_eo_neg_up_lane[0-3] phase_eo_pos_low_lane[0-3] phase_eo_pos_mid_lane[0-3] phase_eo_pos_up_lane[0-3] up_eye_grade_lane[0-3] upper_eye_lane[0-3]
PTYs	data_rate_oper
PPHCR	active_hist_type bin_range_write_mask hist_max_measurement hist_min_measurement hist_type num_of_bins pphcr_local_port pphcr_pnat we

Register / Page Name	Field List
SLSIR	ae_state_lane[0-3] cal_abort_cnt_lane[0-3] cal_done_cnt_lane[0-3] cdr_abort_cnt_lane[0-3] cdr_done_cnt_lane[0-3] cdr_error_lane[0-3] eom_abort_cnt_lane[0-3] eom_done_cnt_lane[0-3] eq_abort_cnt_lane[0-3] eq_done_cnt_lane[0-3] feq_adc_overload_lane[0-3] imem_chksm_error_lane[0-3] nop_dsovf_error_lane[0-3] nop_dsunf_error_lane[0-3] nop_rsovf_error_lane[0-3] nop_rsunf_error_lane[0-3] peq_adc_overload_lane[0-3] rd_iter_cnt_lane[0-3] rx_cal_ugl_state_lane[0-3] rx_eom_ugl_state_lane[0-3] rx_eq_ugl_state_lane[0-3] rx_init_abort_cnt_lane[0-3] rx_init_done_cnt_lane[0-3] rx_ugl_state_lane[0-3] sd_hits_cnt_lane[0-3] sd_iter_cnt_lane[0-3] tx_ugl_state_lane[0-3]
SLTP	alev_minus_bfm2_lane[0-3] alev_plus_bfm2_lane[0-3] blev_lane[0-3] main_tap_lane[0-3] ob_alev_out_lane[0-3] ob_amp_lane[0-3] ob_bad_stat_lane[0-3] ob_m2lp_lane[0-3] obnlev_lane[0-3] obplev_lane[0-3] post_tap_lane[0-3] pre_2_tap_lane[0-3] pre_tap_lane[0-3] regn_bfm1p_lane[0-3] regp_bfm1n_lane[0-3] sltp_status_lane[0-3] tx_alev_lane[0-3]

Register / Page Name	Field List
PMDR	clp_[1,4]x cluster gb_valid gearbox_die_num ib_port label_port_query local_port local_port_query lp_msb mcm_tile_num mcm_tile_valid module module_lane_mask physical_rx_lane[0-3] physical_tx_lane[0-3] pll_index pmdr_status pnat pport sd_4x_rx sd_4x_tx sd_lane_mask_rx sd_lane_mask_tx slot_index split swid tile_cluster tile_pport usr_sd_4x_rx usr_sd_4x_tx version vl_num

Register / Page Name	Field List
PPLL	ae_pll[0-3] analog_var_pll[0-3] bg_trim cal_abort cal_abort_sticky cal_done cal_en cal_error_counter cal_internal_state cal_main_state cal_valid_sticky clear_cause_pll[0-3] clock_valid_pll[0-3] dco_coarse dco_coarse_bin fctrl_measure_pll[0-3] high_var_pll[0-3] lma_rcal_code lma_rcal_tx_n_code lma_rcal_tx_p_code lock_clk_val_cause_pll[0-3] lock_lost_counter_pll[0-3] lock_pll[0-3] lock_pulse_pll[0-3] lock_status_pll[0-3] lockdet_cnt_based_lock lockdet_err_cnt_active_lock lockdet_err_cnt_locked_sticky lockdet_err_cnt_unlocked_sticky lockdet_err_measure_done lockdet_err_state lokcdet_error_count low_var_pll[0-3] mid_var_pll[0-3] num_plls_[7,16]nm pll_lockdet_state pll_pwrup_pll[0-3] pll_speed_pll[0-3] pll_ugl_state plllock_clk_val_pll[0-3] pwr_up_state rcal_done_valid_sticky rcal_fsm_done rcal_tx_n_valid_sticky rcal_tx_p_valid_sticky speedo vref_trim

Register / Page Name	Field List
SLLM	ber_mon_exp_lane[0-3] ber_mon_lane[0-3] ber_mon_mantissa_lane[0-3] cdr_offset_peq_en_lane[0-3] ctle_peq_cnt_lane[0-3] ctle_peq_en_lane[0-3] dffe_peq_en_lane[0-3] dffe_peq_scout_skip_lane[0-3] ib[1,3]_max_lm_90_tries_lane[0-3] lm_active_lane[0-3] lm_clk90_fl_err_acc_lane[0-3] lm_clk90_fl_err_max_lane[0-3] lm_counter_dn_lane[0-3] lm_counter_mid_lane[0-3] lm_counter_up_lane[0-3] lm_en_lane[0-3] lm_was_active_lane[0-3] peq_adc_vref_step_lane[0-3] peq_dffe_delay_lane[0-3] peq_dffe_iters_lane[0-3] peq_train_mode_lane[0-3] peq_tsense_en_lane[0-3] peq_vref_iters_lane[0-3] pib_gw_lock_lane[0-3] vref_peq_en_lane[0-3]
PHY BER Params	alarm_th_eff_ber alarm_th_raw_ber alarm_th_sym_ber normal_th_eff_ber normal_th_raw_ber normal_th_sym_ber port_type_eff_ber port_type_raw_ber port_type_sym_ber rs_fec_group_eff_ber rs_fec_group_raw_ber rs_fec_group_sym_ber sampling_rate_eff_ber sampling_rate_raw_ber sampling_rate_sym_ber time_window_eff_ber time_window_raw_ber time_window_sym_ber warning_th_eff_ber warning_th_raw_ber warning_th_sym_ber
MRCS	max_delta_freq_[0-1] max_freq_[0-1] measured_freq_[0-1] min_freq_[0-1]
PEMI Module Samples	pemi_dp_st_lane[0-7] pemi_module_st pemi_rx_power_lane[0-7] pemi_temperature pemi_tx_bias_lane[0-7] pemi_tx_power_lane[0-7] pemi_voltage

Register / Page Name	Field List
PEMI SNR Samples	snr_host_lane[0-7] snr_media_lane[0-7]
PEMI Laser Samples	laser_age laser_frequency_error_lane[0-7] laser_temperature_lane[0-7] tec_current
PEMI Pam4 Samples	pam4_level_transition_host_lane[0-7] pam4_level_transition_media_lane[0-7]
PEMI Pre FEC BER Samples	pre_fec_ber_avg_host pre_fec_ber_avg_media pre_fec_ber_max_host pre_fec_ber_max_media pre_fec_ber_min_host pre_fec_ber_min_media pre_fec_ber_val_host pre_fec_ber_val_media
PEMI Pre FEC BER Properties	pre_fec_ber_avg_high_host_alarm pre_fec_ber_avg_high_host_warning pre_fec_ber_avg_high_media_alarm pre_fec_ber_avg_high_media_warning pre_fec_ber_cap pre_fec_ber_max_high_host_alarm pre_fec_ber_max_high_host_warning pre_fec_ber_max_high_media_alarm pre_fec_ber_max_high_media_warning pre_fec_ber_min_high_host_alarm pre_fec_ber_min_high_host_warning pre_fec_ber_min_high_media_alarm pre_fec_ber_min_high_media_warning
PEMI Ferc Samples	ferc_avg_host ferc_avg_media ferc_max_host ferc_max_media ferc_min_host ferc_min_media ferc_val_host ferc_val_media
PHY Counters	link_down_events

Register / Page Name	Field List
PHY Statistics	conf_level_raw_ber eff_ber effective_ber_coef effective_ber_magnitude phy_corrected_bits phy_effective_errors phy_raw_errors_lane[0-3] phy_received_bits phy_symbol_errors raw_ber raw_ber_coef raw_ber_coef_lane[0-3] raw_ber_lane[0-3] raw_ber_magnitude raw_ber_magnitude_lane[0-3] symbol_ber symbol_ber_coef symbol_ber_magnitude time_since_last_clear
PHY InfiniBand General Counters	dqs2llu_xmit_wait_arb_global general_transmit_discard_external_contain grxb_fecn_mark port_rcv_data_qword port_sw_hoq_lifetime_limit_discards port_xmit_data_qword port_xmit_ebp rq_general_error
Histograms	fc_zero_hist hist[0-15]
Troubleshoot	group_opcode status_message status_opcode

Register / Page Name	Field List
Operation Info	cable_proto_cap cable_proto_cap_ext core_to_phy_link_enabled core_to_phy_link_proto_enabled core_to_phy_link_width_enabled eth_100g_fec_support eth_25g_50g_fec_support eth_an_fsm_state eth_an_link_enabled fec_mode_request ib_phy_fsm_state loopback_mode neg_mode_active pd_fsm_state pd_link_enabled pddr_fec_mode_active pddr_link_speed_active pddr_link_width_active phy_hst_fsm_state phy_hst_link_enabled phy_manager_link_enabled phy_manager_link_proto_enabled phy_manager_link_width_enabled phy_mngr_fsm_state profile_fec_in_use proto_active psi_fsm_state retran_mode_active retran_mode_request
Link Down Info	ber_exp ber_mantissa down_blame e2e_reason_opcode last_ber_exp last_ber_mantissa local_reason_opcode max_ber_exp max_ber_mantissa min_ber_exp min_ber_mantissa num_of_ber_alarams remote_reason_opcode
Link Up Info	fast_link_up_status time_to_link_up time_to_link_up_disable_to_pd time_to_link_up_disable_to_sd time_to_link_up_phy_up_to_active time_to_link_up_sd_to_phy_up up_reason_drv up_reason_mng up_reason_pwr

Register / Page Name	Field List
PLR	hi_retransmission_rate plr_rcv_code_err plr_rcv_codes plr_rcv_uncorrectable_code plr_sync_events plr_xmit_codes plr_xmit_retry_codes plr_xmit_retry_codes_within_t_sec_max plr_xmit_retry_events
Port VL	PortRcvDataSLExt[0-15] PortRcvDataVLExt[0-15] PortRcvPktVLExt[0-15] PortVLXmitFlowCtlUpdateErrors[0-15] PortVLXmitTimeCongExt[0-15] PortXmitDataSLExt[0-15] PortXmitDataVLExt[0-15] PortXmitPktVLExt[0-15] PortXmitWaitVLExt[0-15]
MLNX Counters Page0	rq_num_dup rq_num_lae rq_num_leeo rq_num_lle rq_num_lpe rq_num_lpqoe rq_num_mce rq_num_oos rq_num_rae rq_num_retrans_rsync rq_num_rire rq_num_roe rq_num_wrf sq_num_bre sq_num_ldb_drops sq_num_leeo sq_num_lle sq_num_lpe sq_num_lpqoe sq_num_mwbe sq_num_oos sq_num_rabrt sq_num_rae sq_num_retrans_rsync sq_num_rire sq_num_rnr sq_num_roe sq_num_rree sq_num_to sq_num_tree sq_num_wrf

Register / Page Name	Field List
MLNX Counters Page1	max_cnak_fifo_size maximum_dcdrs minimum_dcdrs rq_close_non_gb_gc rq_curr_gb_connect rq_curr_gb_reconnect rq_dcr_inhale_events rq_gb_trap_cnak rq_not_gb_connect rq_not_gb_reconnect rq_num_cnak_sent rq_num_dc_cacks rq_num_no_dcdrs rq_num_sig_err rq_open_gb rq_open_gb_cnak rq_state_active_gb rq_state_avail_dcdrs rq_state_dcr_lifo_size sq_cnak_drop sq_num_cnak sq_num_dc_cacks sq_num_sig_err sq_reconnect sq_reconnect_ack sq_reconnect_ack_bad
MLNX Counters Page255	dc_has_max_used_entries_in_line dc_hash_curr_used_lines num_cqovf num_eqovf rq_close_gb_gc rq_cwc_ghost_discard_connect rq_cwc_ghost_discard_reconnect rq_cwc_reconnect_probable_current_connection rq_cwc_reconnect_stale_connection rq_cwc_uncertainty_discard rq_next_gb_connect rq_next_gb_reconnect rq_num_dc_cacks_collision rq_num_dc_cacks_full_hash rq_psn_close_gb rq_psn_close_gb_cwc sq_num_ds_ex_pi_retry

Register / Page Name	Field List
Sharp PM Counters	ack_packet_sent aeth_syndrome_ack_packet hba_multi_packet_message_dropped_bytes hba_multi_packet_message_dropped_pkts hba_received_bytes hba_received_pkts hba_sent_ack_bytes hba_sent_ack_packets hba_sharp_lookup oos_nack_rcv packet_discard_sharp packet_discard_transport packet_sent rcds_send_bytes rcds_sent_packets retry_packet_sent rnr_event rnr_nack_rcv timeout_event
General Info	build_id device_hw_rev device_id device_technology fw_date_dmy fw_hour fw_ini_ver fw_version hw_uptime psid sw_version
Device Temperature	dev_temperature
Port Counters	excessive_buffer_errors link_down_counter link_error_recovery_counter local_link_integrity_errors port_rcv_constraint_errors port_rcv_data port_rcv_errors port_rcv_pkts port_rcv_remote_physical_errors port_rcv_switch_relay_errors port_xmit_constraint_errors port_xmit_data port_xmit_discard port_xmit_pkts port_xmit_wait symbol_error_counter vl15_dropped

Register / Page Name	Field List
Port Counters Extended	ExcessiveBufferOverrunErrorsExtended LinkDownedCounterExtended LinkErrorRecoveryCounterExtended LocalLinkIntegrityErrorsExtended PortMultiCastRcvPktsExtended PortMultiCastXmitPktsExtended PortRcvConstraintErrorsExtended PortRcvDataExtended PortRcvErrorsExtended PortRcvPktsExtended PortRcvRemotePhysicalErrorsExtended PortRcvSwitchRelayErrorsExtended PortUniCastRcvPktsExtended PortUniCastXmitPktsExtended PortXmitConstraintErrorsExtended PortXmitDataExtended PortXmitDiscardsExtended PortXmitPktsExtended PortXmitWaitExtended QP1DroppedExtended SymbolErrorCounterExtended VL15DroppedExtended
Extended Speeds Counters	ErrorDetectionCounterLane.[0-11] FECCorrectableBlockCountrLane.[0-11] FECCorrectedSymbolCounterLane.[0-11] FECUncorrectableBlockCounterLane.[0-11] PortFECCorrectableBlockCounter PortFECCorrectedSymbolCounter PortFECUncorrectableBlockCounter RetransmissionPerSec SyncHeaderErrorCounter UnknownBlockCounter
LLR Statistics	MaxRetransmissionRate
Port Rcv Error Details	PortBufferOverrunErrors PortDLIDMappingErrors PortLocalPhysicalErrors PortLoopingErrors PortMalformedPacketErrors PortVLMappingErrors
Port Xmit Discard Details	PortInactiveDiscards PortNeighborMTUDiscards PortSwHOQLifetimeLimitDiscards PortSwLifetimeLimitDiscards
Port RN Counters	pfrn_received_error pfrn_received_packet pfrn_start_packet pfrn_xmit_packet port_ar_trials port_rcv_rn_error port_rcv_rn_pkt port_rcv_switch_relay_rn_error port_xmit_rn_pkt

Register / Page Name	Field List
Port HBF Counters	rx_pkt_forwarding_ar rx_pkt_forwarding_ar_sg[0-2] rx_pkt_forwarding_hbf rx_pkt_forwarding_hbf_sg[0-2] rx_pkt_forwarding_static rx_pkt_hbfFallback_local rx_pkt_hbfFallback_remote
Fast Recovery Counters	consecutive_normal_credit_watchdog consecutive_normal_eff_ber consecutive_normal_raw_ber consecutive_normal_sym_ber counter_overflow_credit_watchdog counter_overflow_eff_ber counter_overflow_raw_ber counter_overflow_sym_ber last_value_[0-2]_credit_watchdog last_value_[0-2]_eff_ber last_value_[0-2]_raw_ber last_value_[0-2]_sym_ber max_value_credit_watchdog max_value_eff_ber max_value_raw_ber max_value_sym_ber min_value_credit_watchdog min_value_eff_ber min_value_raw_ber min_value_sym_ber num_errors_credit_watchdog num_errors_eff_ber num_errors_raw_ber num_errors_sym_ber num_normals_credit_watchdog num_normals_eff_ber num_normals_raw_ber num_normals_sym_ber num_warnings_credit_watchdog num_warnings_eff_ber num_warnings_raw_ber num_warnings_sym_ber
Port Hierarchy	bus device function m ASIC m cage m label m port m slot type m slot value m split m type
Link Partner	link_partner_description link_partner_lid link_partner_node_guid link_partner_port_num

Register / Page Name	Field List
Ports	fec_mode_active link_speed_active link_width_active logical_state phy_state pi_fec_mode_active pi_link_speed_active pi_link_width_active
Calculated Info	NormalizedXW Normalized_CBW Normalized_XmitData infiniband_CBW

9.2 Cable Info

Telemetry supports the following field list for cable information.

```

node_guid
port_guid
sys_image_guid
Port
aport
Lid
node_type
port_type
num_planes
Port_Name
Vendor
vendor_oui
PN
SN
Rev
smf_length
LengthCopperOrActive
Identifier
cable_identifier
Connector
Type
ib_compliance_code
length
length_by_prtl
length_by_reg
cable_type
SupportedSpeedDesc
Temperature
PowerClass
CDREnableTxRx
tx_cdr_enable
rx_cdr_enable

```

cable_tx_equalization
cable_rx_amp
OutputEmp
cable_rx_emphasis
cable_rx_post_emphasis
fw_version
mi_rx_power_type
HighTemperatureAlarm
LowTemperatureAlarm
HighTemperatureWarning
LowTemperatureWarning
InitializationFlagComplete
HighSupplyVoltageAlarm
LowSupplyVoltageAlarm
HighSupplyVoltageWarning
LowSupplyVoltageWarning
diag_supply_voltage
transmitter_technology
ActiveWavelengthControl
CooledTransmitterDevice
ActivePinDetector
TunableTransmitter
ExtendedSpecificationComplianceCodes
temperature_high_th
temperature_low_th
WarnTemperatureHighThresh
WarnTemperatureLowThresh
voltage_high_th
voltage_low_th
WarnVoltageHighThresh
WarnVoltageLowThresh
rx_power_high_th
rx_power_low_th
tx_power_high_th
tx_power_low_th
tx_bias_high_th
tx_bias_low_th
date_code
Lot
RXOutputDisable
TXAdaptiveEqualizationEnable
max_power
cable_vendor
ib_width
wavelength
ethernet_compliance_code
cable_breakout
tx_cdr_cap
rx_cdr_cap
memory_map_rev
wavelength_tolerance

```
module_st
rx_output_valid
rx_input_valid
active_set_host_compliance_code
active_set_media_compliance_code
tx_input_freq_sync
error_code
did_cap
cdr_vendor
max_fiber_length
dp_fw_fault
mod_fw_fault
tx_fault
rx_output_valid_change
rx_input_valid_change
temperature_alarm_and_warning
voltage_alarm_and_warning
tx_los
tx_cdr_lol
tx_ad_eq_fault
tx_power_hi_al
tx_power_lo_al
tx_power_hi_war
tx_power_lo_war
tx_bias_hi_al
tx_bias_lo_al
tx_bias_hi_war
tx_bias_lo_war
rx_los
rx_cdr_lol
rx_power_hi_al
rx_power_lo_al
rx_power_hi_war
cable_temperature
link_partner
HighRX[1-4]PowerAlarm
HighRX[1-4]PowerWarning
HighTX[1-4]BiasAlarm
HighTX[1-4]BiasWarning
HighTX[1-4]PowerAlarm
HighTX[1-4]PowerWarning
LengthOM[1-5]
LowRX[1-4]PowerAlarm
LowRX[1-4]PowerWarning
LowTX[1-4]BiasAlarm
LowTX[1-4]BiasWarning
LowTX[1-4]PowerAlarm
LowTX[1-4]PowerWarning
RX[1-4]CDRLOL
RX[1-4]LatchedLossIndicator
TX[1-4]AdaptiveEqualizationFaultIndicator
```

```

TX[1-4]AdaptiveEqualizationFreeze
TX[1-4]CDRLOL
TX[1-4]LatchedLossIndicator
cable_attenuation_2_5g
cable_attenuation_[5,7,12,25]g
dp_st_lane[0-3]
nbr_250
node_guid_plane_[0-3]
port_num_plane_[0-3]
rx_power_lane[0-7]
tx_bias_lane[0-7]
tx_power_lane[0-7]

```

9.2.1 Supported Docker Statistics

- mem_buffers - relatively temporary storage for raw disk blocks that should not become exceptionally large
- mem_cached - memory in the pagecache (diskcache) minus SwapCache—does not include SwapCached
- mem_free - sum of free lowmem and free highmem
- mem_swap_chache - memory that was once swapped out is swapped back in but is still kept in the swap file
- mem_total - total usable RAM
- mlnx:total_read_time - time spent on reading all counters
- clx_cpu_load
- clx_pid
- clx_res_mem
- clx_shr_mem
- clx_virt_mem

Type	Field
cable	timestamp node_guid port_guid Lid ActivePinDetector ActiveWavelengthControl CDREnableTxRx Connector CooledTransmitterDevice ExtendedSpecificationComplianceCodes HighRX[1-4]PowerAlarm HighRX[1-4]PowerWarning HighSupplyVoltageAlarm HighSupplyVoltageWarning HighTX[1-4]BiasAlarm HighTX[1-4]BiasWarning HighTX[1-4]PowerAlarm HighTX[1-4]PowerWarning HighTemperatureAlarm HighTemperatureWarning Identifier InitializationFlagComplete

Type	Field
	LengthCopperOrActive LengthOM[1-5] Lot LowRX[1-4]PowerAlarm LowRX[1-4]PowerWarning LowSupplyVoltageAlarm LowSupplyVoltageWarning LowTX[1-4]BiasAlarm LowTX[1-4]BiasWarning LowTX[1-4]PowerAlarm LowTX[1-4]PowerWarning LowTemperatureAlarm LowTemperatureWarning OutputEmp PN Port Port_Name PowerClass RXOutputDisable RX[1-4]CDRLOL RX[1-4]LatchedLossIndicator Rev SN SupportedSpeedDesc TXAdaptiveEqualizationEnable TX[1-4]AdaptiveEqualizationFaultIndicator TX[1-4]AdaptiveEqualizationFreeze TX[1-4]CDRLOL TX[1-4]LatchedLossIndicator Temperature TunableTransmitter Type Vendor WarnTemperatureHighThresh WarnTemperatureLowThresh WarnVoltageHighThresh WarnVoltageLowThresh active_set_host_compliance_code active_set_media_compliance_code cable_attenuation_2_5g cable_attenuation_[5,7,12,25]g cable_breakout cable_identifier cable_rx_amp cable_rx_emphasis cable_rx_post_emphasis cable_temperature cable_tx_equalization cable_type cable_vendor date_code diag_supply_voltage did_cap dp_fw_fault dp_st_lane[0-3] error_code ethernet_compliance_code fw_version ib_compliance_code

Type	Field
	ib_width length link_partner max_power memory_map_rev mi_rx_power_type mod_fw_fault module_st nbr_250 rx_cdr_cap rx_cdr_enable rx_cdr_lol rx_input_valid rx_input_valid_change rx_los rx_output_valid rx_output_valid_change rx_power_hi_al rx_power_hi_war rx_power_high_th rx_power_lane[0-3] rx_power_lo_al rx_power_low_th smf_length temperature_alarm_and_warning temperature_high_th temperature_low_th transmitter_technology tx_ad_eq_fault tx_bias_hi_al tx_bias_hi_war tx_bias_high_th tx_bias_lane[0-3] tx_bias_lo_al tx_bias_lo_war tx_bias_low_th tx_cdr_cap tx_cdr_enable tx_cdr_lol tx_fault tx_input_freq_sync tx_los tx_power_hi_al tx_power_hi_war tx_power_high_th tx_power_lane[0-3] tx_power_lo_al tx_power_lo_war tx_power_low_th vendor_oui voltage_alarm_and_warning voltage_high_th voltage_low_th wavelength wavelength_tolerance

9.3 Switch Info

The following table lists the supported register names by telemetry, along with their respective field lists.

Register Name	Field List
temp_fields	node_guid sensor_index mtmp_sensor_name temperature max_temperature
power_fields	node_guid sensor_index mvcr_sensor_name voltage current feed_managed voltage_managed power_managed current_managed capacity_managed
total_power_managed_fields	node_guid total_power_managed
power_supplies_fields	node_guid psu_idx ac_status dc_status alert_psu present_psu fan_psu temp_psu power_consumption power_cap snp serial_number_psu
managed_power_supplies_fields	node_guid psu_idx power_managed_sup voltage_managed_sup current_managed_sup module_desc_managed_sup sensor_managed_sup status_managed_sup
fan_fields	node_guid sensor_index fan_speed fan_speed_f[1-2]_managed

Register Name	Field List
general_fields	node_guid serial_number part_number revision product_name random_fdb_cap linear_fdb_cap linear_fdb_top mcast_fdb_cap optimized_slvl_mapping port_state_change life_time_value def_mcast_not_pri_port def_mcast_pri_port def_port part_enf_cap lids_per_port mcast_fdb_top filter_raw_outb_cap filter_raw_inb_cap outb_enf_cap inb_enf_cap enp0

9.4 PCI Info

The following field list of PCI info is supported by telemetry.

```

node_guid
pci_node
pcie_index
depth
fw_version
device_id
device_technology
mvcr_sensor_name
mtmp_sensor_name
switch_voltage
switch_current
switch_temperature
switch_serial_number
switch_part_number
capability_mask
link_speed_enabled
link_width_enabled
link_speed_active
link_width_active
num_of_vfs
num_of_pfs
lane_reversal
port_type

```

pwr_status
max_payload_size
max_read_request_size
pci_power
link_peer_max_speed
port_state
device_status
receiver_detect_result
life_time_counter
life_time_counter_low
life_time_counter_high
rx_errors
tx_errors
crc_error_dllp
crc_error_tlp
tx_overflow_buffer_pkt
tx_overflow_buffer_marked_pkt
outbound_stalled_reads
outbound_stalled_writes
outbound_stalled_reads_events
outbound_stalled_writes_events
effective_ber_coeff
effective_ber_magnitude
effective_ber_pci
time_since_last_clear_high
time_since_last_clear_low
life_time_counter_high_lanes
life_time_counter_low_lanes
life_time_counter_high_timers
life_time_counter_low_timers
time_to_boot_image_start
time_to_link_image
calibration_time
time_to_first_perst
time_to_detect_state
time_to_crs_en
time_to_plastic_image_start
time_to_iron_image_start
perst_handler
dl_down
correctable_err_msg_sent
non_fatal_err_msg_sent
fatal_err_msg_sent
bdf0
config_cycle16to63usec
config_cycle2to7usec
config_cycle8to15usec
config_cycle[1,64]usec
error_counter_lane[0-15]
l0_to_recovery_eieos
l0_to_recovery_framing

```

l0_to_recovery_retrain
l0_to_recovery_ts
lane0_physical_position
time_to_l0
times_in_l[1,23]

```

9.5 NVLink Info

The table below lists the supported register names by telemetry, along with their corresponding field lists.

Register Name	Field List
nvl_class_port_info_fields	node_guid CapMsk ClassVersion BaseVersion RespTimeValue RedirectGID RedirectFL RedirectSL RedirectTC RedirectPKey RedirectLID RedirectQP RedirectQKey TrapGID TrapFL TrapSL TrapTC TrapPKey TrapLID TrapQP TrapHL TrapQKey CapMsk2
nvl_hbf_config_fields	node_guid port_num hash_type packet_hash_bitmask seed fields_enable
nvl_reduction_port_info_fields	node_guid port_num port_direction_is_up exclude_include_self
nvl_reduction_config_mlid_fields	node_guid port_num mlid[0-7]
nvl_reduction_info_fields	node_guid reduction_FDB_Cap hbf_group_cap reduction_fdb_top num_of_up_ports num_of_down_ports

Register Name	Field List
nvl_cdrain_info_fields	node_guid port_guid port_num di_ingress_port_state di_egress_port_state
nvl_cdrain_port_state_fields	node_guid port_guid port_num dps_ingress_port_state dps_egress_port_state
nvl_reduction_counters_fields	node_guid port_guid port_num block lean_pipe_select mlid incoming_good_mc_read_req_pkt incoming_good_mc_read_req_data incoming_good_mc_write_req_pkt incoming_good_mc_write_req_data incoming_good_mc_read_resp_pkt incoming_good_mc_read_resp_data incoming_good_mc_write_resp_pkt incoming_good_mc_write_resp_data generated_mc_read_resp_pkt generated_mc_read_resp_data generated_mc_write_resp_pkt generated_mc_write_resp_data dropped_pkt trapped_pkt nvl_reduction_errors nvl_reduction_penalty_box_errors port_nvr_local_alm_id_allocations port_nvr_global_alm_id_allocations
nvl_reduction_rounding_fields	node_guid bf16 e4m3 e5m2 fp[16,32,64]
nvl_anycast_lid_fields	
nvl_penalty_box_fields	
nvl_reduction_forwarding_fields	
nvl_qos_config_vl_fields	

10 Document Revision History

Revision and Date	Description
Rev 1.7.0 - May 5, 2024	<p>Updated:</p> <ul style="list-style-type: none"> • Changes and New Features in This Release • Bug Fixes in This Release • Updated step 4 (start collection) command in Deploying UFM Telemetry - Bringup Mode • Fixed format of "ibdiagnet2_port_counters.log" file name in Log File Rotation <p>Added:</p> <ul style="list-style-type: none"> • Port Counters and Events • Distributed Telemetry - Switch Telemetry Agent • Supported Telemetry Fields
Rev 1.16.5 - February 2024	<p>Updated:</p> <ul style="list-style-type: none"> • Changes and New Features in This Release • Bug Fixes in This Release • Settings and Configuration - added <code>m_key</code>:
Rev 1.15.6 - December 2023	<p>Updated:</p> <ul style="list-style-type: none"> • Bug Fixes in This Release • Known Issues in This Release • Software Management - Updated package paths and reorganized the chapter <p>Added:</p> <ul style="list-style-type: none"> • Bare Metal - Bringup Mode
Rev 1.15 - November 2023	<p>Updated:</p> <ul style="list-style-type: none"> • Changes and New Features in This Release • Bug Fixes in This Release • Settings and Configuration - Added <code>f orce_hca</code> key <p>Added:</p> <ul style="list-style-type: none"> • Switch Power Sensors Data • Switch Power Supplies Data • SHARP HW Counters
Rev 1.14.5 - August 2023	Updated Bug Fixes in This Release
Rev 1.14 - August 2023	<p>Updated:</p> <ul style="list-style-type: none"> • Changes and New Features in This Release • Bug Fixes in This Release • Extended Counter Set Filtering
Rev 1.13.7 - June 2023	<p>Updated:</p> <ul style="list-style-type: none"> • Changes and New Features in This Release • Bug Fixes in This Release
Rev 1.13.5 - May 2023	<p>Updated:</p> <ul style="list-style-type: none"> • Bug Fixes in This Release
Rev 1.13 - May 2023	<p>Updated:</p> <ul style="list-style-type: none"> • Changes and New Features in This Release • Bug Fixes in This Release • Data Filtering - Added <code>/xcset</code> filter file • Configuring Data Polling Endpoint • URL Prefixes Priority <p>Added:</p> <ul style="list-style-type: none"> • Managed Switch Data Collection • Extended Counter Set Filtering

Revision and Date	Description
Rev 1.12 - February 2023	<p>Updated:</p> <ul style="list-style-type: none"> • Changes and New Features in This Release • Bug Fixes in This Release • Updated Docker Container in Software Management • Docker Container Mode - High Availability • Cset Fset Filtering • Configuring Data Polling Endpoint • Cable Info <p>Added:</p> <ul style="list-style-type: none"> • Deploying UFM Telemetry Bare Metal - High Availability • Enable MLNX_COUNTERS
Rev 1.11 - November 2022	<p>Updated:</p> <ul style="list-style-type: none"> • Changes and New Features in This Release • System Requirements • Bug Fixes in This Release • Upgrading UFM Telemetry Software to list instructions on all modes of operation • Software Management • Settings and Configuration <p>Added:</p> <ul style="list-style-type: none"> • Bug Fixes History • Enable PPCC • Enable XMIT_WAIT per vl • Log File Rotation • Docker Container Mode - High Availability
Rev 1.10 - July 2022	<p>Updated:</p> <ul style="list-style-type: none"> • Software Management
Rev 1.9 - May 2022	<p>Added:</p> <ul style="list-style-type: none"> • Section Deploying UFM Telemetry - Bringup Mode • Section Bringup - amBer Format <p>Updated:</p> <ul style="list-style-type: none"> • NVIDIA UFM TELEMETRY USER MANUAL • Software Management • Data Collection • Fluent Bit Export • Settings and Configuration • Prometheus Endpoint Support
Rev 1.8 - November 30, 2021	<p>Added:</p> <ul style="list-style-type: none"> • Bare Metal Mode • Container Mode • Deploying UFM Telemetry Bare Metal
Rev 1.7 - August 30, 2021	Added page Prometheus Endpoint Support
Rev 1.7 - March 29, 2021	Updated step 6 in section Deploying UFM Telemetry due to new licensing mechanism
Rev 1.7 - February 08, 2021	No changes
Rev 1.6 - January 27, 2021	<p>Added:</p> <ul style="list-style-type: none"> • Upgrading UFM Telemetry Software • Fluent Bit Export • UFM Telemetry Configuration Script • Switch Temperature • Switch Fans • Switch General • Appendixes

Revision and Date	Description
Rev 1.0 - August 27, 2020	First release

Notice

This document is provided for information purposes only and shall not be regarded as a warranty of a certain functionality, condition, or quality of a product. Neither NVIDIA Corporation nor any of its direct or indirect subsidiaries and affiliates (collectively: "NVIDIA") make any representations or warranties, expressed or implied, as to the accuracy or completeness of the information contained in this document and assumes no responsibility for any errors contained herein. NVIDIA shall have no liability for the consequences or use of such information or for any infringement of patents or other rights of third parties that may result from its use. This document is not a commitment to develop, release, or deliver any Material (defined below), code, or functionality.

NVIDIA reserves the right to make corrections, modifications, enhancements, improvements, and any other changes to this document, at any time without notice. Customer should obtain the latest relevant information before placing orders and should verify that such information is current and complete.

NVIDIA products are sold subject to the NVIDIA standard terms and conditions of sale supplied at the time of order acknowledgement, unless otherwise agreed in an individual sales agreement signed by authorized representatives of NVIDIA and customer ("Terms of Sale"). NVIDIA hereby expressly objects to applying any customer general terms and conditions with regards to the purchase of the NVIDIA product referenced in this document. No contractual obligations are formed either directly or indirectly by this document.

NVIDIA products are not designed, authorized, or warranted to be suitable for use in medical, military, aircraft, space, or life support equipment, nor in applications where failure or malfunction of the NVIDIA product can reasonably be expected to result in personal injury, death, or property or environmental damage. NVIDIA accepts no liability for inclusion and/or use of NVIDIA products in such equipment or applications and therefore such inclusion and/or use is at customer's own risk.

NVIDIA makes no representation or warranty that products based on this document will be suitable for any specified use. Testing of all parameters of each product is not necessarily performed by NVIDIA. It is customer's sole responsibility to evaluate and determine the applicability of any information contained in this document, ensure the product is suitable and fit for the application planned by customer, and perform the necessary testing for the application in order to avoid a default of the application or the product. Weaknesses in customer's product designs may affect the quality and reliability of the NVIDIA product and may result in additional or different conditions and/or requirements beyond those contained in this document. NVIDIA accepts no liability related to any default, damage, costs, or problem which may be based on or attributable to: (i) the use of the NVIDIA product in any manner that is contrary to this document or (ii) customer product designs.

No license, either expressed or implied, is granted under any NVIDIA patent right, copyright, or other NVIDIA intellectual property right under this document. Information published by NVIDIA regarding third-party products or services does not constitute a license from NVIDIA to use such products or services or a warranty or endorsement thereof. Use of such information may require a license from a third party under the patents or other intellectual property rights of the third party, or a license from NVIDIA under the patents or other intellectual property rights of NVIDIA.

Reproduction of information in this document is permissible only if approved in advance by NVIDIA in writing, reproduced without alteration and in full compliance with all applicable export laws and regulations, and accompanied by all associated conditions, limitations, and notices.

THIS DOCUMENT AND ALL NVIDIA DESIGN SPECIFICATIONS, REFERENCE BOARDS, FILES, DRAWINGS, DIAGNOSTICS, LISTS, AND OTHER DOCUMENTS (TOGETHER AND SEPARATELY, "MATERIALS") ARE BEING PROVIDED "AS IS." NVIDIA MAKES NO WARRANTIES, EXPRESSED, IMPLIED, STATUTORY, OR OTHERWISE WITH RESPECT TO THE MATERIALS, AND EXPRESSLY DISCLAIMS ALL IMPLIED WARRANTIES OF NONINFRINGEMENT, MERCHANTABILITY, AND FITNESS FOR A PARTICULAR PURPOSE. TO THE EXTENT NOT PROHIBITED BY LAW, IN NO EVENT WILL NVIDIA BE LIABLE FOR ANY DAMAGES, INCLUDING WITHOUT LIMITATION ANY DIRECT, INDIRECT, SPECIAL, INCIDENTAL, PUNITIVE, OR CONSEQUENTIAL DAMAGES, HOWEVER CAUSED AND REGARDLESS OF THE THEORY OF LIABILITY, ARISING OUT OF ANY USE OF THIS DOCUMENT, EVEN IF NVIDIA HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. Notwithstanding any damages that customer might incur for any reason whatsoever, NVIDIA's aggregate and cumulative liability towards customer for the products described herein shall be limited in accordance with the Terms of Sale for the product.

Trademarks

NVIDIA, the NVIDIA logo, and Mellanox are trademarks and/or registered trademarks of NVIDIA Corporation and/or



Mellanox Technologies Ltd. in the U.S. and in other countries. Other company and product names may be trademarks of the respective companies with which they are associated.

Copyright

© 2024 NVIDIA Corporation & affiliates. All Rights Reserved.

